


SMS TEXT MESSAGING

Receive and send text messages from your paired and linked compatible phone. Visit handsfreelink.honda.com to check if this feature is compatible with your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

Receiving Text Messages

Use the selector knob to make and enter selections.


1. A notification appears on the i-MID. Select Yes to open the message.
2. The message is displayed, and the system reads it aloud.



Replying to Text Messages

Use the selector knob to make and enter selections.

1. With the message open, press the selector knob to enter the Text Message Menu.
2. Select Reply.
3. Select one of the six available reply messages.
4. Select Yes to send the message.



Calling the Sender

Use the selector knob to make and enter selections.

1. With the message open, press the selector knob to enter the Text Message Menu.
2. Select Call to begin the call.

