ECO ASSIST™

When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system are adjusted to maximize fuel efficiency.

Turning ECON Mode On/Off

I. Press ECON.



2. The ECON mode indicator comes on.





3. Check the i-MID for the system status.



4. Press ECON again to turn the system off.

Ambient Meter


Indicates real-time fuel efficiency using color-coded bars.



This feature can be turned off in the Customize Settings Menu. See your Owner's Manual for more information.

Driver Feedback





Driving Style	Eco Drive Bar (on the i-MID)	Ambient Meter Background Color Changes	Fuel Efficiency
Smooth, steady acceleration high fuel efficiency			High
Smooth, steady deceleration high fuel efficiency		mph	
Moderate acceleration			
Moderate deceleration		mpn	
Rapid acceleration low fuel efficiency			
Rapid deceleration low fuel efficiency		mph	Low
Goals: • Keep the Eco Drive bar notes the Ambient Meter			

Real-time Fuel Efficiency Coach


- ECO Assist Scoring

• Develop a driving style that maximizes fuel efficiency.


into leaves, which are displayed in a series of five "plant" icons on the i-MID.

Once you start your vehicle, make sure the i-MID shows the Ecological Drive Display to view your Eco Assist score in real time.


Monitors the fuel efficiency of your driving style in real time and converts results







Each time you reach a new stage, a Stage Up Recognition icon briefly appears on the i-MID. When you reach the highest ranking, a Trophy icon briefly appears.



Drive Cycle Score

Last Stage Up

Recognition