HOMELINK®

Program your vehicle to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

Training a Button



- Position the remote transmitter you wish to link 1–3 inches from the HomeLink button you want to program.
- Press and hold the desired HomeLink button and the button on the remote transmitter.

Does the HomeLink indicator (LED) blink at a faster rate after about 10 seconds?

NO

NO

YES

- Press and hold the button on the remote and the HomeLink button at the same time. Then, while continuing to hold the HomeLink button, press and release the button on the remote every 2 seconds.
 - Does the LED blink at a faster rate within 20 seconds?

YES

Press and hold the programmed HomeLink button for about a second.

Does the device (garage door opener) work?

NO

4 Press and hold the HomeLink button again.

Training complete

HomeLink indicator HomeLink LED flashes for 2 seconds, remains on.

- The remote has a rolling code.
 Press the "learn" button on the remote-controlled device (e.g., garage door opener).
- b Within 30 seconds, press and hold the programmed HomeLink button for 2 seconds.
- Press the programmed HomeLink button again; the remote-controlled device should operate.

If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit www.homelink.com.