

BASIC AUDIO OPERATION

Operate basic controls of your audio system using various convenient methods.

Steering Wheel Controls

Volume increase button

◀ button: Go to previous stations or tracks.

Volume decrease button



SOURCE button: Change audio source.

▶ button: Go to next stations or tracks.

Audio Panel Controls

Audio sources: Select FM/AM, CD, or AUX.

Selector knob: Rotate and press to make and enter selections.

BACK button: Return to the previous display or cancel a selection.



Skip/Seek buttons: Change stations or tracks.

MENU button: Select options for the selected audio source.

USB Connection



Connect the iPhone or iPod cable or a USB flash drive to the USB port in the front console.


Connect your device only when your vehicle is stopped.

iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Playing Audio Files


1. Connect the iPod cable or USB flash drive to the USB port in the front console.
2. Press SOURCE or AUX until iPod or USB appears.
3. Press the SKIP buttons to change tracks.



iPod is a trademark of Apple, Inc.

Searching for Music

1. Press MENU. Use the selector knob to make and enter selections.
2. Select Music Search.
3. Select a category or folder.
4. Select a track to begin playing.




BLUETOOTH® AUDIO

Play stored or streaming audio from your compatible phone through your vehicle's audio system. Visit handsfreelink.honda.com to check if this feature is compatible with your phone.

Playing *Bluetooth* Audio

1. Make sure your phone is on and paired to *Bluetooth*® HandsFreeLink®.
2. Press SOURCE or AUX until *Bluetooth* Audio appears.
3. From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system. Make sure the volume on your phone is properly adjusted.
4. Press the SKIP buttons to change tracks.



Notes:

- You may need to enable additional Bluetooth settings on your phone for playback.
- The play/pause function and remote audio controls are not supported on all phones.
- Operate your phone only when your vehicle is stopped.