
PADDLE SHIFTING

While in the D position, 7-Speed Manual Shift Mode allows you to manually shift your vehicle's speeds up or down. Useful for engine braking or when driving in hilly terrain or cornering. Available on vehicles with automatic transmission.


Paddle Modes







Pull (+) to shift up.




NORMAL or ECON Mode

- Pull (+) or (-) to temporarily switch from automatic to manual shift mode.
- The speed number is displayed on the shift indicator display.
- When the vehicle's speed is constant, the mode returns to automatic.

SPORT Mode

- Pull (+) or (-) to switch to manual shift mode.
- The M indicator and speed number are displayed on the shift indicator display.
- Pull (+) or (-) to change transmission speeds.





• Pull and hold (+) to cancel this mode.

L (Low) Mode

- Pull and hold (+) and (-) at the same time until L is displayed on the shift indicator display.
- Use this mode to get higher torque when climbing steep hills.
- Pull and hold again to cancel this mode.

