


INFORMATION DISPLAY

Consists of several displays that provide you with useful information.


Reading the Display

These items are shown on each display.



Changing the Display

You can change the information in the middle display.



Press the select/reset knob to change displays.


Odometer,
Trip meter A




Range,
Trip meter A



Average fuel
economy A,
Trip meter A



Average fuel
economy B,
Trip meter B



Engine oil life



Clock
adjustment

