



INFORMATION DISPLAY

Consists of several displays that provide you with useful information.

Accessing the Information Display



When you start the engine, the display shows your last active selection from the previous drive cycle.




To toggle between the different displays, press and release the select/reset knob repeatedly.

Information Displays

Odometer,
Outside
temperature



Fuel range,
Instant fuel
economy



Oil life



Trip meter
A/B, Average
fuel economy

