■ Steering Wheel Controls

You can operate certain functions of the audio system using the steering wheel controls.

Models with color audio

SOURCE button: Cycle through available audio modes.

+ / - buttons: Adjust audio volume.

◀ / ▶ buttons: Change presets, tracks, albums, or folders



FM/AM Radio

Press ◀ or ▶ for the next or previous preset station.

Press and hold ◀ or ▶ to seek the next or previous strong station.

iPod/USB/Bluetooth Audio

Press ◀ or ▶ for the next or previous track.

Press and hold ◀ or ▶ for the next or previous folder (USB).

Models with Display Audio

button: Press until the audio screen is displayed in the Driver Information Interface.

+/- bar: Press the ends of the bar or slide to adjust audio volume. On models with SPORT mode, press the ends of the bar to adjust audio volume.

◀ / ▶ buttons: Change presets, tracks, albums, or folders.



FM/AM/SiriusXM Radio*

Press ◀ or ▶ for the next or previous preset station.

Press and hold ◀ or ▶ to seek the next or previous strong station.

Press ENTER to display the list of preset stations.

iPod/USB/Bluetooth Audio

Press ◀ or ▶ for the next or previous track.

Press and hold ◀ or ▶ for the next or previous folder (USB).

Pandora*

Press ► for the next song.

Press and hold ◀ or ▶ for the next or previous station.

■ Steering Wheel Controls (continued)

Models with Display Audio (continued)

▲ / ▼ buttons: Cycle through available audio modes, or scroll through audio options in the Driver Information Interface

ENTER button: Make audio selections in the Driver Information Interface.

From the audio screen in the Driver Information Interface:

FM/AM/SiriusXM Radio*

Press the ENTER button to display a preset list. Press \triangle or ∇ to scroll the list, and press the ENTER button to select a preset.

USB Flash Drive

Press the ENTER button to display the folder list. Press \triangle or ∇ to scroll the list, and press the ENTER button to select a folder. Repeat to select a track.

iPod

Press the ENTER button to display the iPod list. Press \triangle or ∇ to scroll the category, and press the ENTER button to select an item. Repeat to select a track.

Bluetooth Audio

Press the ENTER button to display the track list. Press ▲ or ▼ to scroll the list, and press the ENTER button to select a track.

Pandora*

Press the ENTER button to display the station list. Press ▲ or ▼ to scroll the list, and press the ENTER button to select a station.

6 000 6

Models with Display Audio Basic HFL Operation

Make and receive phone calls using the vehicle's audio system, without handling your phone. Visit *automobiles.honda.com/handsfreelink* to check phone compatibility.

To reduce the potential for driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Stop or pull over to perform the function. Voice commands are also available.

■ HFL Controls

Use the controls to enter information and make selections.

Hang-Up/Back button: End or decline a call, or cancel an operation.

Pick-Up button: Answer an incoming call. -

Talk button: Make a call using a stored voice tag, or—say voice commands*.

button: Press until the phone screen is displayed in the Driver Information Interface.

▲ / ▼ buttons: Scroll the phone list in the Driver Information Interface.


ENTER button: From the phone screen in the Driver Information Interface, select from Speed Dial, Call History, or Phonebook.



Models with Display Audio

Siri® Eyes Free

Activate Siri through your vehicle when an iPhone is paired to the system. Visit *automobiles.honda.com/handsfreelink* to check phone compatibility.



Here are some examples of Siri commands:

"Call John Smith"

"Read my new text message"

"Find a nearby sushi restaurant"

"Remind me to pick up dinner"

"Set up a meeting today at 3 p.m."

"Play song XYZ"

Notes:

- Any requests that include visual feedback from Siri on your phone are not displayed in the vehicle.
- Certain commands rely on the iPhone's features and existing apps.
- To hear turn-by-turn directions or songs through the vehicle, set the audio source to Bluetooth Audio.
- If using Siri Eyes Free through Apple CarPlay, use the Talk button to activate and deactivate Siri Eyes Free mode.