



Models with Display Audio

Touchscreen Operation

Use simple gestures—including touching, swiping, and scrolling—to operate certain audio functions.

Some items may be grayed out during driving to reduce the potential for distraction. You can select them when the vehicle is stopped or use voice commands*.

Wearing gloves may limit or prevent touchscreen response.



**if equipped*

■ Setting Touchscreen Sensitivity

You can adjust the touchscreen's sensitivity to your fingertip.

1. From the HOME screen, select Settings, then System.
2. Select Others, then Touch Panel Sensitivity.
3. Make your selection.

Models with Display Audio

Managing Apps

Customize the Home screens by adding, moving, and hiding apps. Use presets to keep frequently used apps at your fingertips.

■ Add Apps to a Home screen

1. On the Home screen, Select and hold the home screen.
2. Select Add.
3. Drag and drop the icon to where you want it to be, Select Done.



■ Move Apps

1. On the Home screen, select and hold an icon.
2. Drag and drop it where you would like it.
3. Select Done



■ Hide Apps

1. On the Home screen, select and hold an icon.
2. Drag and drop it on the Hide icon.
3. Select Done.



■ Set Shortcuts

1. On the Home screen, select and hold an icon.
2. Drag and drop it the upper-left corner of the screen.
3. Select Done.



Models with Display Audio

HondaLink®*

Provides you with useful information about your vehicle directly from Honda.


To check phone compatibility, visit automobiles.honda.com/handsfreelink/ (U.S.) or call (888) 528-7876 (Canada). Standard data rates may apply with your phone service provider.

To get more information on HondaLink, visit www.hondalink.com (U.S.) or honda.ca/hondalink (Canada).

■ HondaLink Connection

Follow the steps below to connect to HondaLink and use its features.

1. Download the HondaLink Connect app to your compatible smartphone.
2. Pair your phone to *Bluetooth HandsFreeLink*.
3. From the HOME screen, select HondaLink.



**if equipped*

Do not install apps other than those confirmed by a Honda dealer. Unauthorized apps may have privacy and data corruption risks.

4. Certain features require you to send vehicle information to Honda. Select Enable Once, Always Enable, or Disable.

■ HondaLink Menu

Select a menu option.

Connect: Displays instruction messages when the vehicle needs service.
Help & Support: Display tips for vehicle usage, get roadside assistance, or contact customer service.


Messages from Honda: Display helpful and important information from Honda. If you have a new message, a yellow envelope icon appears at the top of the screen and a beep sounds. Swipe down to view the message.

■ Operator Assistance*

Connect to a HondaLink operator for roadside assistance or help finding a destination.

To place a call: Press the Link button.

To end a call: Select Hang Up on the audio/information screen or press the hang-up button on the steering wheel.



Models with Display Audio

HondaLink® Assist*

If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle automatically attempts to connect to an operator. Your phone must be paired to the system and have good cellular connection. Visit www.hondalink.com (U.S.) or honda.ca/hondalinkassist (Canada) for more information.**

Models with Display Audio

Near Field Communication (NFC)*

Near Field Communication (NFC) allows you to connect select Android phones to the audio system via *Bluetooth*.

1. From the Home screen, Select Settings.
2. Select Connections.
3. Select NFC, then ON.
4. Select Android Beam, then ON.

**if equipped*

***Depending on your phone and cellular signal capability, your vehicle's location may not be sent to the operator.*

■ **Bluetooth Setup**

1. From the Home screen, select NFC Manager. Or touch the NFC logo near the glove box with the NFC tag of your phone. The NFC Manager screen is displayed.
2. Select Connect Device to Vehicle Bluetooth.
3. Touch the NFC logo near the glove box with the NFC tag of your phone.
4. A notification appears on the screen if pairing is successful. Confirm if the pairing code on the screen and your phone match.
5. This may vary by phone.

■ **Wallpaper Image Transfer**

1. From the Home screen, select NFC Manager or touch the NFC logo near the glove box with the NFC tag of your phone.
2. Select Transfer Image.
3. Open the photo you want to transfer on your phone, then select Next.
4. Touch the NFC logo near the glove box with the NFC tag of your phone.
5. Select the photo on your phone.
6. A confirmation message appears on the screen. Select Wallpaper.

Models with Display Audio


Apple CarPlay™

Connect an Apple CarPlay-compatible iPhone to the system. You can use the touchscreen to make a phone call, listen to music, and more. Visit the Apple CarPlay website for more information.

When your iPhone is connected to Apple CarPlay, it is not possible to use the *Bluetooth* Audio or *Bluetooth* HandsFreeLink. However, other previously paired phones can stream audio via *Bluetooth* while Apple CarPlay is connected.

Park in a safe place before connecting your iPhone and launching any compatible apps.

1. Connect the iPhone to the USB port (2.5A) in the center pocket or console compartment*.
2. Apple CarPlay requires you to send vehicle information to Honda. Select Enable to continue. Your phone may prompt you to allow access for CarPlay to be launched.
3. From the HOME screen, select Apple CarPlay.
4. Select a menu option.
5. **Phone:** Access your contacts, make phone calls, or listen to voicemail. While connected to Apple CarPlay, calls can only be made through Apple CarPlay, not through Bluetooth HandsFreeLink.
6. **Music:** Play music stored on your iPhone.



Maps: View a map and operate navigation. You can only use Apple Maps or the pre-installed navigation system to set a destination with routing guidance.

Messages: View and reply to text messages, or have messages read to you aloud by the system.

Once connected, press and hold the Talk button on the steering wheel (see p. 74) to operate the system using voice commands with Siri.

Depending on use, Apple CarPlay can share certain vehicle information (e.g., vehicle location, speed, and other operating conditions) with the connected iPhone. See Apple's privacy policy for details regarding Apple's use and handling of data uploaded by CarPlay. Use of CarPlay is at user's own risk, and is subject to agreement to the CarPlay terms of use, which are included as part of the Apple iOS terms of use. CarPlay vehicle integration is provided "as is," and Honda cannot guarantee CarPlay operability or functionality now or in the future due to, among other conditions, changes in CarPlay software/Apple iOS, service interruptions, or incompatibility or obsolescence of vehicle-integrated hardware or software. See dealer for details. Only use CarPlay when conditions allow you to do so safely. See your Owner's Manual at owners.honda.com (U.S.) or myhonda.ca (Canada) for further license and warranty terms.

**if equipped*

Models with Display Audio

Android Auto™

Connect a compatible Android phone to the system. You can use the touchscreen to make a phone call, listen to music, and more. Visit the Android Auto website for more information.


When your Android phone is connected to Android Auto, it is not possible to use the *Bluetooth Audio*. However, other previously paired phones can stream audio via *Bluetooth* while Android Auto is connected.

Park in a safe place before connecting your Android smartphone and launching any compatible apps.

1. Connect the phone to the USB port (2.5A) in the center pocket or console compartment*. Compatible Android phones will prompt you to download any required apps.

2. Select Enable or Disable
3. Follow any prompts shown on your phone.
4. The phone will be automatically paired. A tutorial will appear on the vehicle screen.

5. Select a menu option



1. **Maps (Navigation):** View Google Maps and operate navigation. You can only use this system or the pre-installed navigation system to set a destination with routing guidance. You cannot enter destinations using the keyboard while the vehicle is moving.
2. **Phone (Communication):** Make or receive phone calls or listen to voicemail.
3. **Google Now (Home screen):** Display useful information organized by Android Auto into simple cards that appear only when needed.
4. **Music and audio:** Play music from compatible apps. Select this icon to switch between music apps.
5. **Go back to the Home Screen:** Select this icon to return to the HOME screen.
6. **Voice:** Use voice commands to operate Android Auto. You can also press and hold the Talk button on the steering wheel to say voice commands.

Depending on use, Android Auto can share certain vehicle information (e.g., vehicle location, speed, and other operating conditions) with Google and its service providers. See Google privacy policy for details regarding Google's use and handling of data uploaded by Android Auto. Use of Android Auto is at user's own risk, and is subject to agreement to the Android Auto terms of use, which are presented to the user when the Android Auto application is downloaded to the user's Android phone. Android Auto vehicle integration is provided "as is," and Honda cannot guarantee Android Auto operability or functionality now or in the future due to, among other conditions, changes in Android Auto software/Android operating system, service interruptions, or incompatibility or obsolescence of vehicle-integrated hardware or software. See dealer for details. Only use Android Auto when conditions allow you to do so safely. See your Owner's Manual at owners.honda.com (U.S.) or myhonda.ca (Canada) for further license and warranty terms.



Models with Display Audio

Wi-Fi Connection

You can connect the audio system to the internet using Wi-Fi. If your compatible phone has hotspot capabilities, the system can be tethered to the phone. Follow the steps below to set up Wi-Fi when the vehicle is stopped. Standard data rates apply with your phone service provider.

1. From Home, select Settings
2. Select Connections, then Wi-Fi.
3. Select Change Mode.
4. Select Network, then Save.
5. Select an available network from the list.
6. If required, enter a password, then select Connect.

The connected network will be displayed at the top of the list when the connection is successful.



Models with Display Audio



System Updates

Install authorized updates to the Display Audio system software. Install via a WiFi connection or a USB storage device.

■ Wireless Connection Setup


These steps are required only for updating via Wi-Fi.

1. From the Home screen, select System Updates, then Settings.
2. Select Connection Setup.
3. Select Wi-Fi, then Change Mode.
4. Select Network, then Confirm.
5. Select an access point.
6. Ensure Use this network... is checked, then select Connect.



■ Wireless Updating



1. From the Home screen, select System Updates.
2. Select via Wireless
3. Select Download Now.
4. Select Install Now or Install While Vehicle OFF.



■ USB Updating

Download the update

1. From the Home screen, select System Updates, then via USB.
2. Connect a flash drive to the USB port in the center pocket or console compartment*.
3. Once the system finishes copying to the flash drive, disconnect the drive and connect it to your computer.
4. Follow the link to download the update files. See *usb.honda.com* for more details.



Install the update

1. From the Home screen, select System Updates, then via USB.
2. Connect the USB device containing the update files to the USB port in the center pocket or console compartment*.
3. Select Install Now.

Notes

- Honda recommends using a flash drive with 8GB capacity or higher.

**if equipped*

Models with Display Audio

FM/AM Radio


Play FM or AM radio stations.

Volume/Power Knob:

Push to turn on/off audio. Turn to adjust volume

Presets icons:

Select and hold a preset number to store the current station. Select a preset number to select a previously stored station.



**if equipped*

Models with Display Audio


SiriusXM® Radio*

Available on a subscription basis only. For more information or to subscribe, contact your dealer, or visit www.sirius.com/subscribe-now (U.S.) or www.sirius.ca/subscribe-now (Canada).

Presets:

Select and hold a preset number to store the current station.

Select a preset number to select a previously stored station.



To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual at owners.honda.com (U.S.) or myhonda.ca (Canada).


*Available in the U.S. and Canada, except Hawaii, Alaska, and Puerto Rico.
XM® is a registered trademark of Sirius XM Radio, Inc.*

**if equipped*

Models with Display Audio

iPod®


Play and operate an iPod through the vehicle's audio system. Connect your device to the USB port.



■ Searching for Music

Use the touchscreen to search for tracks stored on the iPod.

1. Select Browse.
2. Select the items on that menu.



iPod is a trademark of Apple, Inc.