

Models with Display Audio

HondaLink[®] Assist*

If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle automatically attempts to connect to an operator. Your phone must be paired to the system and have good cellular connection. Visit www.hondalink.com (U.S.) or honda.ca/hondalinkassist (Canada) for more information.**

**if equipped*

***Depending on your phone and cellular signal capability, your vehicle's location may not be sent to the operator.*