

Models with Color Audio

Pandora®

Play and operate Pandora® from your phone through the vehicle's audio system. Visit automobiles.honda.com/handsfreelink/ (U.S.) or call (888) 528-7876 (Canada) to check phone compatibility. Standard data rates apply.

Connect your phone when the vehicle is stopped. To use this service in your vehicle, the Pandora® app must first be installed on your phone. Visit www.pandora.com for more information.

For iPhone:

- Connect via *Bluetooth®* HandsFreeLink® or USB port.
- A pop-up may appear on your phone requesting you to allow access for Pandora to be launched.
- If you cannot operate Pandora® through the audio system, it may be streaming through *Bluetooth®* Audio. Make sure Pandora® is selected on the audio system.
- If Pandora® still does not operate, try rebooting the phone and reconnecting the cable if necessary.

For Android or BlackBerry:

- Connect via *Bluetooth®* HandsFreeLink®.

Media button: Press to select Pandora (if connected)

The diagram shows a car's audio control panel with the following features and callouts:

- Media button:** Located on the left side of the panel, below the 'RADIO' and 'MEDIA' buttons.
- Skip button:** A button with a double right-pointing arrow, located below the 'MEDIA' button.
- Preset buttons:** A row of six buttons numbered 1 through 6, located at the bottom center of the panel.
- Selector knob:** A large circular knob on the right side of the panel, used for changing stations.
- Other controls:** A volume knob on the left, a 'CLOCK MENU' button on the right, and a 'LIST/SELECT' button below the 'CLOCK MENU' button.

Skip button: Go to the next song.

Preset buttons: Press the button for each function.

- (1) Pause/resume
- (2) Dislike song
- (3) Like song
- (4) Bookmark track

Selector knob: Rotate to change the station.

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle. Launch streaming audio on your phone only when safe to do so.