

Models with Display Audio

SMS Text Messaging

Certain phones can receive and send messages when paired and connected. Visit automobiles.honda.com/handsfreelink/ (U.S.) or call (888) 528-7876 (Canada) to check phone compatibility. Standard message rates apply with your phone service provider. The system does not display any received messages while you are driving. You can only hear them read aloud.

Text messaging is not available while using Apple CarPlay. Use Apple Messages instead.



■ Receiving and Responding to Messages

When you receive a new message, a pop-up appears on the touchscreen. You can view the message when the vehicle is stopped. You can also reply to it using fixed phrases or call the sender.

1. When the pop-up appears, select **Open**. The message displays.
2. Select **Play** to have the system read the message aloud.

To reply: With the message open, select **Reply**. Select one of the six available responses. Select **Send** to send the message.

To call the sender: With the message open, select **Call**.



**if equipped*