VOICE COMMAND INDEX

Learn about all available voice commands to help you operate the vehicle. Available on vehicles with navigation. The system recognizes only the commands listed here.

Press the Talk button before you say a command. To view a list of available commands in the vehicle, say *"Voice help."* Select a category to hear the commands read aloud.

■ General Commands

The system accepts these commands on any screen.

- Voice help
- Display menu
- Display setting
- Display navigation
- Display information

- Display audio
- Display phone
- Back/Cancel
- What is today's date?
- What time is it?

■ Navigation Commands

The system accepts these commands on the map/guidance screen.

General Commands

- Display map
- Display navigation
- Go home 1 (or 2)

Map Display Commands

- Display current location
- Display/Hide (specify icon type):

  – ATM
  – gas station
  – restaurant
  – post office
  – grocery store
  – lodging (hotel, motel)
  – parking garage
  – parking lot
  – school

  – hospital
  – freeway exit information
  – traffic*
  – traffic speeds*
  – traffic icons*
- Display north up
- Display heading up
- Display 3D map
- Display zoom in
- Display zoom out

U.S. models only

■ Navigation Commands (continued)

Find Place Commands

- Find nearest (specify place):
  - Fuel and auto
  - Honda dealers
  - Gas station
  - Auto parts & electronics
  - Auto repair & maintenance
  - Car wash & detailing
  - Motorcycle dealers
  - Other car dealerships
  - Roadside assistance
  - ATM
  - Bank
  - Check cashing
  - Currency exchange
  - Community
  - Business
  - City hall
  - Civic center
  - Convention center
  - Court house
  - Higher education
  - Library
  - Post office
  - School
  - Emergency room
  - Hospital
  - Police station
  - Veterinarian
  - Lodging
  - Bed & breakfast
  - Hotel
  - Resort
  - Recreation
  - Amusement park
  - Golf course
  - Historical monument
  - Marina
  - Movie theater
  - Museum
  - Park
  - Performing arts
  - Sports complex
  - Tourist attraction
  - Restaurant
  - American restaurant
  - Californian restaurant
  - Chinese restaurant
  - Coffee shop
  - Continental restaurant
  - Fast food
  - French restaurant
  - German restaurant
  - Greek restaurant
  - Indian restaurant
  - Italian restaurant
  - Japanese restaurant
  - Korean restaurant
  - Mexican restaurant
  - Pizza
  - Seafood restaurant
  - Thai restaurant
  - Vegetarian restaurant
  - Vietnamese restaurant
  - Other restaurant
  - Shopping
  - Shopping area
  - Accessory store
  - Book store
  - Clothing store
  - Grocery store
  - Home improvement store
  - Mall
  - Office supply store
  - Pharmacy
  - Pet food store
  - Sewing store
  - Shoe store
  - Sporting goods store
  - Toy store

- Travel center
- Airport
- Automobile club
- Bus station
- Camping
- Commuter rail station
- Ferry terminal
- Named place
- Park & ride
- Parking garage
- Parking lot
- Rental car agency
- Rest area
- Ski area
- Tourist information
- Train station
- Travel agency
- Truck stop

Route Commands

The system accepts these commands when a route is set.

- How long to the destination?
- How far to the destination?
- Display destination map
- Display entire route
- Cancel route
- Repeat guidance
- Route menu

■ Climate Control Commands**

The system accepts these commands on most screens. **Available on Canadian models only.**

- Climate control automatic (maintains selected temperature)
- Climate control on*
- Climate control off*
- Air conditioner on*
- Air conditioner off*
- Rear defrost on*
- Rear defrost off*
- Climate control fresh air
- Climate control recirculate
- Climate control vent
- Climate control bi-level (vent and floor
- Climate control floor
- Climate control floor and defrost
- Fan speed up
- Fan speed down
- Fan speed # (#: 1 to 7)
- Temperature # degrees (#: 57 to 87°F / 15 to 29°C)
- Temperature up
- Temperature down
- Driver temperature up
- Driver temperature down
- Temperature max heat
- Temperature max cool

*These commands toggle the function on and off, so the command may not match your intended action.
**if equipped

Audio Commands

The system accepts these commands on most screens. Audio volume levels cannot be controlled using voice commands.

FM/AM Radio Commands

- Audio on*
- Audio off*
- Radio on*
- Radio off*
- Radio select FM
- Radio select AM
- Radio tune to # FM (#: frequency, e.g., 95.5)
- Radio tune to # AM (#: frequency, e.g., 1020)
- Radio seek up
- Radio seek down
- Radio next station
- Radio preset # (#: 1 to 12)
- Radio FM preset # (#: 1 to 12)
- Radio AM preset # (#: 1 to 6)
- Radio scan*

SiriusXM® Radio Commands

- Radio select XM
- XM channel # (#: 0 to 255)
- XM channel up
- XM channel down
- XM category up
- XM category down
- XM preset # (#: 1 to 12)
- XM scan*
- XM category scan*
- XM channel scan*
- XM category mode
- XM channel mode

Disc Commands

- Disc play
- Disc play track # (#: 1 to 30)
- Disc skip forward
- Disc skip back
- Disc track random*
- Disc track repeat*
- Disc track scan*
- Disc folder up
- Disc folder down
- Disc folder random*
- Disc folder repeat*
- Disc folder scan*
- Disc normal play

Song By Voice™ Commands

Available for iPod and USB music search.

- Music search
- What am I listening to?
- Who am I listening to?
- Who is this?
- Who's playing?
- What's playing?
- What album is this?
- Play artist (name)
- Play track/song (name)
- Play album (name)
- Play genre/category (name)
- Play playlist (name)
- Play composer (name)
- List artist (name)
- List album (name)
- List genre/category (name)
- List playlist (name)
- List composer (name)

These commands toggle the function on and off, so the command may not match your intended action.

■ Audio Commands (continued)

USB Commands

- Music search
- USB play
- USB play track # (#: 1 to 30)
- USB skip forward
- USB skip back
- USB track random*
- USB track repeat*
- USB track scan*
- USB folder up
- USB folder down
- USB folder random*
- USB folder repeat*
- USB folder scan*
- USB normal play

iPod® Commands

- Music search
- iPod play
- iPod play track # (#: 1-30)
- iPod skip forward
- iPod skip back
- iPod track shuffle*
- iPod album shuffle*
- iPod track repeat*
- iPod normal play
- What/Who am I listening to?
- Who is this?
- What's playing?
- Who's playing?
- What album is this?

Pandora® Commands**

- Pandora play*
- Pandora skip forward
- Pandora station up
- Pandora station down
- Pandora pause*
- Pandora resume*
- Pandora thumbs up
- Pandora thumbs down

Bluetooth® Audio Commands

- Bluetooth audio play
- Bluetooth audio skip forward
- Bluetooth audio skip back
- Bluetooth audio pause
- Bluetooth audio resume
- Bluetooth audio group up
- Bluetooth audio group down

  Commands may not work on some phones or devices.

AUX Commands

- Auxiliary play

*These commands toggle the function on and off, so the command may not match your intended action.

**U.S. models only

Phone Commands

The system accepts these commands on most screens.

- Dial/call by number
- Dial/call by name
- Call (phone number or name)

Info Commands

The system accepts these commands on most screens.

- Trip computer
- Display traffic list*
- Display traffic on my route*
- Display clock
- Display wallpaper

On-screen Commands

The system accepts these commands on any screen where applicable. All available commands are highlighted in yellow when you press the Talk button.

- Next (or previous)
- Up (or down)
- Right (or left)
- Return
- OK (excluding Startup Confirmation screen)
- Delete

if equipped