


■ Sequential Mode

Use the paddle shifters to change gears without removing your hands from the steering wheel.

(-) Paddle shifter: Pull to shift down to a lower gear.



(+) Paddle shifter: Pull to shift up to a higher gear.



When the transmission is in D: The vehicle goes into sequential shift mode momentarily, and the gear selection indicator comes on. When you start traveling at a constant speed, sequential mode and the gear position indicator automatically go off.

When the transmission is in S: The vehicle goes into sequential mode, and the M (sequential mode) indicator and gear selection indicator come on. Use the paddle shifters to change gears.

To cancel this mode, hold the + paddle shifter for two seconds or press D/S again. The M indicator and gear selection indicator go off.