AUDIO AND CONNECTIVITY

Learn how to operate the vehicle's audio system.

Basic Audio Operation

Connect audio devices and operate buttons and displays for the audio system.

■ **USB Port**

Install the iPod® USB connector or the USB flash drive to the USB port.

**In the Center Pocket**

Models with Color Audio

The USB port (1.0A) is for playing audio files on a USB flash drive, connecting a cellular phone and charging devices.

In the Center Pocket

Models with color audio

Models with Display Audio

*1 - If equipped

Accessory power socket (console compartment)

Open the console lid and the cover to use it.

Automatic transmission/Continuously variable transmission models

Manual transmission models

NOTICE

Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

■ **Adjusting the Sound**

Models with Color Audio

Press the sound button, and rotate to scroll through the following choices:

- Bass
- Middle
- Treble
- Fader
- Balance
- Speed-sensitive Volume Compensation

BAS is selectable.

Sound		12:34
BAS	− ‖‖‖‖‖‖‖‖	+
MID	− ‖‖‖‖‖‖‖‖	+
TRE	− ‖‖‖‖‖‖‖‖	+
FAD	R ‖‖‖‖‖‖‖‖	F
BAL	L ‖‖‖‖‖‖‖‖	R
SVC	Mid	

Color Audio System

Use the buttons to control the color audio system.

Audio/Information Screen

☀☾ (Day/Night) Button

RADIO Button

MEDIA Button

◄◄ (Seek/Skip) Button

►►► (Seek/Skip) Button

VOL /⏻ (Volume/Power) Knob

12:34

103.5

FM1

103.5 87.9 90.1 98.1 106.1 107.9

1 2 3 4 5 6

📞 (Phone) Button

♪◄ (Sound) Button

MENU/CLOCK Button

↰ (Back) Button

Selector Knob

Preset Buttons (1-6)