
Homelink® Universal Transceiver*1

Program your vehicle to operate up to three remote-controlled devices around your home—such as garage doors, lighting, or home security systems—using the buttons on the bottom of the rearview mirror.



Training a Button

Park near the system you want to program, and follow the instructions in the flowchart that follows.

1. Position the remote transmitter you wish to link 1 to 3 inches (3 - 8 cm) from the HomeLink® button you want to program. 2. Press and hold the desired HomeLink button. Is the HomeLink indicator (LED) slowly flashing orange? 3a. Hold the button on the remote 3b. Canadian Garage Door Opener transmitter. Does HomeLink indicator A. Press and release the HomeLink (LED) change from slowly flashing button. Press, hold and release the orange to rapidly flashing green or button on the remote every 2 secs. continuously on green? The process Does the HomeLink indicator (LED) should take less than 60 seconds. change from *slowly flashing orange to* rapidly flashing or continuously on 4. Press and hold the programmed HomeLink areen? The process should take less button for about a second. Does the device \(\) than 60 seconds. (garage door opener) work? 5. Press and hold the HomeLink button again. Training HomeLink <u>LED is</u> Complete HomeLink indicator *rapidly flashes* green. 6. Press and hold the HomeLink button **5a.** The remote has a rolling code. Press the again. "learn" button on the remote-controlled The remote-controlled device should device (e.g. garage door opener). operate. 5b. Within 30 secs, press and hold the Training Complete programmed HomeLink button for 2

To retrain a button or erase codes, see the Owner's Manual at *owners.honda.com* (U.S.) or *www.myhonda.ca* (Canada). If you need help, call HomeLink at (800) 355-3515 or visit *www.homelink.com*.