

AUDIO AND CONNECTIVITY


Learn how to operate the vehicle's audio system.

Basic Audio Operation

Connect audio devices and operate buttons and displays for the audio system.

■ USB Port

Your vehicle comes supplied with a USB extension cable that runs from the USB port up through to the front console.



*2: U.S. models only.

Models with Display Audio

The USB port (1.5A) is for charging devices, playing audio files and connecting compatible phones with Apple CarPlay™ or Android Auto™.


In the console compartment*¹

**1 - If equipped*

The USB port (1.0A) is for playing audio files on the USB flash drive and connecting a mobile phone and charging device.

Move the removable beverage holder tray rearward.

In the console compartment




Tip: To prevent any potential issues, be sure to use an Apple MFi Certified Lightning Connector for Apple CarPlay™ or a USB cable certified by USB-IF to be compliant with USB 2.0 Standard for Android Auto™.

■ Accessory Power Socket

There is an accessory power socket in the front console panel. It can be used when the vehicle is in ACCESSORY or ON.

Open the cover to use it.




NOTICE

Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

■ Audio Remote Controls

You can operate certain functions of the audio system using the steering wheel controls.



Volume Bar (+/-): Press the +/- at the ends of the bar to adjust the volume.

Up/Down Arrows: Press to cycle through the available audio modes.

■ Adjusting the Sound

Models with Display Audio

1. Press the Sound button.
2. Select Menu.
3. Select Sound.

Select a tab from the following choices:




- BAS-MID-TRE: Bass, Middle, Treble
- FAD-BAL-SUBW^{*1}: Fader, Balance, Subwoofer^{*1}

**1 - If equipped*

- SVC-Neural^{*1}: Speed Volume Compensation, DTS Neural SurroundTM ^{*1}

Display Audio System

Use simple gestures—including touching, swiping and scrolling—to operate certain audio functions.



* Not available on all models

**1 - If equipped*

AUDIO AND CONNECTIVITY

Note: Some items may be grayed out during driving to reduce the potential for distraction. You can select them when the vehicle is stopped or use voice commands.

Wearing gloves may limit or prevent touchscreen response.

Wi-Fi Connection*1

You can connect the audio system to the Internet using Wi-Fi and browse websites or use online services on the audio/ information screen. If your phone has wireless hotspot capabilities, the system can be tethered to the phone. Use the following steps to setup.

1. Press the Home button.
2. Select Settings.
3. Select Bluetooth/Wi-Fi.
4. Select the Wi-Fi tab.
5. Select Wi-Fi On/Off Status, then On.
6. Select Wi-Fi Device List.

Make sure your phone's Wi-Fi setting is in access point (tethering) mode.

Select the phone you want to connect to the system.

If you do not find the phone you want to connect in the list, select Scan.

7. Select Connect.

If needed, enter a password for your phone and select OK.

When the connection is successful, the Wi-Fi icon is displayed on the top of the screen.

8. Press the Home button to go back to the home screen.




FM/AM Radio

Play FM or AM radio stations.

**1 - If equipped*

AUDIO AND CONNECTIVITY

Models with Display Audio




*. Some or all of the lists may not be displayed.

SiriusXM®*1

Models with Display Audio

Available on a subscription basis only. For more information or to subscribe, contact your dealer, or visit www.sirius.com/subscribe-now (U.S.) or www.sirius.ca/subscribe-now (Canada).

To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual at owners.honda.com (U.S.) or myhonda.ca (Canada).



*. Some or all of the lists may not be displayed.


iPod®

Play and operate an iPod®*14 through the vehicle's audio system. Connect your device to the USB port (see USB Port).

*14 - iPod and iPhone are trademarks of Apple, Inc.

AUDIO AND CONNECTIVITY

Models with Display Audio




*: Some or all of the lists may not be displayed.

■ Searching for Music

Models with Display Audio

Use the touchscreen to search for tracks stored on the iPod.


1. Select Menu, then select Music Search.
2. Select the items on that menu.



Pandora®*13

Your audio system allows you to listen to music from the Pandora® app on a compatible smartphone. This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® system, or with an iPhone®, you can connect using your USB cable to the USB port.

**13 - US models only, if equipped*




USB Flash Drive

Your audio system reads and plays sound files on a USB flash drive in either MP3, WMA, or format. Connect your USB flash drive to the USB port .

Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle. Launch streaming audio on your phone only when it is safe to do so.

AUDIO AND CONNECTIVITY

Models with Display Audio




*: Some or all of the lists may not be displayed.

■ Searching for Music

Models with Display Audio

Use the touchscreen to search for tracks.


1. Select MENU and select Music Search.
2. Select Music .
3. Select a folder.
4. Select a track.



Bluetooth® Audio

Play streaming or stored audio from your compatible phone when it is paired to **Bluetooth®** HandsFreeLink® (see Pairing a Phone). Visit handsfreelink.com (US) to check phone compatibility. Canada customers can phone (855)-490-7351 for any HandsFreeLink® related inquiry. Standard data rates apply with your phone service provider.

Models with Display Audio



*: Depending on the **Bluetooth®** device you connect, some or all of the lists may not be displayed.


Applicable laws may prohibit the operation of handheld electronic devices while operating a vehicle. Launch streaming audio on your phone only when safe to do so.

■ Searching for Music

Models with Display Audio

1. Select MENU.
2. Select Music Search.
3. Select a search category (e.g., Albums).
4. Select an item.

The selection begins playing.



Note:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional settings on your phone for playback.
- The resume/pause function and remote audio controls are not supported on all phones.