

### Eco Assist® System

Can help improve your efficiency by adjusting the performance of the power system, transmission, climate control system, and cruise control.




#### Ambient Meter

Color-coded bars change based on your driving style and brake or accelerator pedal operation. **Green:** Energy-efficient driving **White-green:** Moderate acceleration/ deceleration **White:** Aggressive acceleration/ deceleration **Red:** SPORT mode is on



## **Eco Drive Display**

Keep the vehicle in the center of the display to maximize your driving efficiency.




# **Deceleration Paddle Selector**


Use the deceleration paddle selector to control the rate of deceleration. This simulates engine braking as it recovers energy via regenerative braking and helps you keep a distance between your vehicle and a vehicle ahead.

To select the different stages of deceleration, do this:

- 1. Pull back the + selector (right side) to decrease the deceleration stage.
- 2. Pull back the selector (left side) to increase the deceleration stage.

Pull the (+) selector for a few seconds when you want to cancel the deceleration paddle selector.





# 

Be careful not to decelerate too quickly. Rapid deceleration can cause the tires to skid, resulting in loss of control of the vehicle.

In the following situations, the deceleration stage may decrease or cancel automatically:

- The high voltage battery is fully charged or its temperature is too cold or too hot.
- The speed of the vehicle is beyond the deceleration range.
- Power system protection is needed.
- The paddle selector is operated while your vehicle is stopped automatically by ACC with LSF.

## SPORT mode OFF

The deceleration stage will self-cancel when you drive at a constant speed or approach a complete stop.

### SPORT mode ON

The deceleration stage will not self-cancel. To cancel, turn the SPORT mode OFF or pull the + selector (right side) for a few seconds.

## **SPORT Mode**

Enhances the vehicle's agility and responsiveness. SPORT mode is set to off every time the power system is started.

### SPORT Button

Press the SPORT button to turn the mode on or off. A SPORT Mode indicator and a message in the driver information interface appear when the system is on.

