Customized Features

When you customize settings, make sure that the vehicle is at a complete stop and shift to Park (P).

Models with Color Audio

Audio/Information Screen

📞 (Phone) Button

Settings

12:34

Display Change
Wallpaper
Color Theme

MENU/CLOCK Button

Selector Knob

■ **How to Change a Setting**

Models with Color Audio

Use the selector knob to make and enter selections.

1. Press the MENU/CLOCK button.
2. Select Settings.
3. Select a setting option and make your preferred changes.
4. Press the Back button to exit the menus.

Setting the Clock

On vehicles with navigation, the time is automatically set using GPS signals.

On vehicles without navigation and if the Automatic Date & Time feature has been turned off, use the following steps to adjust the time in the clock display.

Models with Color Audio

1. Press and hold the **MENU/CLOCK** button.

2. Rotate **LIST/SELECTOR** knob to change the hour, then press the **LIST/SELECTOR** knob.

3. Rotate **LIST/SELECTOR** knob to change the minute, then press the **LIST/ SELECTOR** knob.

4. To enter the selection, rotate knob, select **Set**, then press the **LIST/ SELECTOR** knob.