Eco Assist® System

Ambient Meter ● The color of the ambient meter changes to green to indicate that the vehicle is being driven in a fuel efficient manner. **Range 200 me.** Average Fuel A. 20,3 mes.** Average Fuel

