Eco Assist® System



 With SPORT mode off, the color of the ambient meter changes to green to indicate that the vehicle is being driven in a fuel efficient manner.




ECON Mode Indicator

Comes on when the ECON button is pressed.



The message is displayed for a few seconds when the **ECON** button is pressed.



ECON Button

Helps maximize fuel economy.