

## Playing SiriusXM® Radio \*

**Channel Icons**  
Select or to the previous or next channel.  
Select and hold to rapidly skip 10 channels at a time.

**Driver Information Interface**

**Album Art**

**Audio/Information Screen**

**Power/AUDIO (Power/Audio) Icon**  
Press to turn the audio system on and off.

**VOL (Volume) Icons**  
Select to adjust the volume.

**(Menu) Icon**  
Select to display the menu items.

**(Back) Icon**  
Select to go back to the previous display.

**Scan Icon**  
Select to scan each channel.

**Category Icons**  
Select or to display and select a SiriusXM® Radio category.

**Station Art**

**Open/Close Icon<sup>\*1</sup>**  
Displays/hides the detailed information.

**Preset Icons**  
Tune the preset radio station. Select and hold the preset icon to store that station. Select to display preset 7 onwards.

**Skip Icons**  
Select or to change section in the channel. Select and hold to move rapidly within the section.

\*1: Some or all of the lists may not be displayed.

\* Not available on all models