


### Customized Features

When you customize settings, make sure that the vehicle is at a complete stop and shift to Park (P) and the power mode set to ON to select Settings. Use the interface to make and enter selections.

#### Using the Driver Information Interface



#### ■ To Change a Setting


1. Select **Vehicle Settings**.
2. Select a category.
3. Select a setting option, and make your preferred changes.

## Setting the Clock

On vehicles with navigation, the time is automatically set using GPS signals. To manually adjust the clock, use the following steps:

### Models with Color Audio

1. Press and hold the **MENU/CLOCK** button.
2. Rotate knob to change the hour, then press the selector knob.
3. Rotate knob to change the minute, then press the selector knob.
4. To enter the selection, rotate knob, select **Set**, then press the **MENU/CLOCK** button.



### Models with Display Audio

1. Press the **Home** button. Select **Settings**.
2. Select **System**.
3. Select **Day & Time**.
4. Select **Set Date & Time**.
5. Select **Automatic Date & Time**, then select **OFF**.
6. Select **Set Time**.
7. Select **the Up or Down arrow**.
8. Select **Save** to set the time.

