


Driver Information Interface

Main Display

Press the home button, then roll the left selector wheel to scroll to the content you want to see. Press the left selector wheel to see detailed information.



* Not available on all models

Sub Display

Press the **TRIP** button to change the display.

