



SMS Text Messaging and E-Mail*1

HFL can display newly received text messages as well as the last 20 messages received on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase.

1. Select the system status icon.
The status area appears.
2. A pop-up appears and notifies you of a new text message.
The text message is displayed.
3. Select Open to display the message.
4. Select Play to listen to the message. To discontinue the message read-out, select Stop.



**1 - If equipped*