


Remote Engine Start *1

Start your vehicle's engine using the smart entry remote before you enter the vehicle.

Starting the Engine

Press the Lock button, then press and hold the Engine button to remotely start the engine.



When started remotely, the engine automatically shuts off after 10 minutes of idling and/or the brake pedal and ENGINE START/STOP button have not been pressed simultaneously.

To extend the run time for another 10 minutes during the first run, press the lock button, then press and hold the engine button.


Note: Make sure the vehicle is in a safe location when using remote engine start (i.e., a well-ventilated area, away from any flammable materials).

Stopping the Engine

When started remotely, the engine shuts off after 10 minutes of idling. It will also stop if the ENGINE START/STOP button and the brake are pressed

**1 - If equipped*

simultaneously. Or you can press and hold the engine button for one second on the smart entry remote to shut the engine off.



WARNING

Carbon monoxide gas is toxic and can rapidly accumulate in closed or even partly enclosed areas.

Breathing it can cause unconsciousness and even kill you.

Never use the remote engine starter with the vehicle parked in a garage or other areas with limited ventilation.