

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd., reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation.

Accessories Precautions

The GPS antenna is located in the dashboard. Metallic front or side window tinting can seriously degrade or obstruct GPS reception.

Signal noise from devices such as radar detectors, vehicle tracking devices, remote starters, and additional amplifiers can disrupt the navigation system. If you install any such item, install it away from the navigation display and antenna.

Important Safety Information

WARNING

Using the navigation system while driving can take your attention away from the road, causing a crash in which you could be seriously injured or killed.

Only operate system controls when the conditions permit you to safely do so.

Avoid focusing on the screen or manually operating the system controls while driving.

Certain on-screen controls are disabled when driving, however most of the voice commands continue to function. Pull to the side of the road if you need to devote more attention and time to look at the screen or access additional menus.

Route guidance may conflict with street closures, road construction, detours, and out-of-date map data.

The system itself may also have limitations. Verify route information by carefully observing roads, signs, and signals. Always use your own judgment and obey traffic laws.


NOTICE


This vehicle's navigation display, if so equipped, includes mercury-containing components. Upon removal, please reuse, recycle, or dispose of as hazardous waste. Clean the screen with a soft, damp cloth. You may use a mild cleaner intended for use on navigation screens.


* Not available on all models

HOME Screen


The system displays various functions from the HOME screen. Press the  (Home) button at any time to return to the main HOME screen.

 (Home)
Display the HOME screen.

 (Back)
Go back to the previous screen.

 (Display Mode)
Switch between Day and Night modes manually.

Navigation
Display the navigation feature that was used the last time.
At start-up, the map screen is displayed.

 (Map)
Display the map screen.

VOL (Volume)
Increase or decrease the audio/
guidance volume.



Features

* Not available on all models

Map Screen Legend

The color of the map is different depending on the selected Map Theme.

Landmark icons

Map operation icons

Map scale


Map tools

Where To?

Streets

Current vehicle position

Feature areas




* Not available on all models

During Route Guidance

During route guidance, route information is displayed on the map screen.

You can see the detailed information on the turn list screen.

Map Screen



Guidance Screen




Day or Night Mode

Press the button to manually switch between Day and Night modes.



Turn-by-Turn Directions

The next guidance point appears on the Driver Information Interface.



* Not available on all models


Navigation—Home Addresses and Going Home


The “Home” feature automatically routes you to your home address from any location simply by selecting **Go Home**.


You can store one home address.

The order of the steps may change depending on the map data loaded on your system.

Storing Your Home Address

1 Press the  button.

2 Select .

3 Select  and then select **Set Home Location**.



4 Select **Enter My Address**.



5 Enter a house number and street name.


6 Select **Done** or a suggestion.

7 Select an address from the list.

8 Select **Select**.



Going Home

1 Press the  button.

2 Select .

3 Select **Go Home**.





Alternatively, you can say  “Navigation” and then  “Go Home” from any screen.

* Not available on all models


Navigation—Entering a Destination

Enter your destination using one of several methods, then follow route guidance on the map to your destination. The order of the steps may change depending on the map data loaded on your system.

1 Press the  button.

2 Select .

3 Select the search bar.



4 Enter the house number and street name.



5 Select **Done** or a suggestion.

6 Select an address from the list.

7 Select **Go!**.

Route guidance to the destination begins.



● **Routes:** Choose one of multiple routes.



● **Info:** Display the location information and save a place.

