
Eco Assist® System



The message is displayed for a few seconds when the

ECON button is pressed.

Helps maximize fuel economy.

ECON Mode Indicator

-ECON Button

Comes on when ECON mode is on.