


Instrument Panel

Gauges /Information Display*/Multi-Information Display*/System Indicators

Models with information display

System Indicators

- Malfunction Indicator Lamp
- Charging System Indicator
- Low Oil Pressure Indicator
- High Temperature Indicator (Red)/Low Temperature Indicator (Blue)
- Vehicle Stability Assist™ (VSA®) System Indicator
- VSA® OFF Indicator
- Electric Power Steering (EPS) System Indicator
- Automatic Brake Hold System Indicator
- Automatic Brake Hold Indicator
- Electric Parking Brake System Indicator
- Electric Parking Brake Indicator



System Indicators

- Maintenance Minder Indicator
- Turn Signal and Hazard Warning Indicators
- ECON Mode Indicator

System Indicators

- CRUISE MAIN Indicator
- CRUISE CONTROL Indicator
- Low Tire Pressure/TPMS Indicator
- All-Wheel Drive (AWD) System Indicator*

Lights Indicators

- Fog Light Indicator*
- High Beam Indicator
- Lights On Indicator













System Indicators

- Supplemental Restraint System Indicator
- Immobilizer System Indicator
- Seat Belt Reminder Indicator
- Door and Tailgate Open Indicator
- Anti-lock Brake System (ABS) Indicator
- Brake System Indicator (Red)
- Brake System Indicator (Amber)
- Low Fuel Indicator
- Brake Depressing Indicator


* Not available on all models

Models with multi-information display






System Indicators

-  Malfunction Indicator Lamp
-  Low Oil Pressure Indicator
-  Charging System Indicator
-  Anti-lock Brake System (ABS) Indicator
-  Vehicle Stability Assist™ (VSA®) System Indicator
-  VSA® OFF Indicator
-  Brake System Indicator (Red)
-  Brake System Indicator (Amber)
-  Automatic Brake Hold System Indicator
-  Automatic Brake Hold Indicator
-  Electric Parking Brake System Indicator
-  Electric Parking Brake Indicator




Shift Lever Position Indicator/ Transmission System Indicator














System Indicators

-  High Temperature Indicator (Red)/Low Temperature Indicator (Blue)
-  Smart Entry System Indicator*
-  ECON Mode Indicator
-  System Message Indicator
-  Low Tire Pressure/TPMS Indicator*

Lights Indicators

-  Lights On Indicator
-  High Beam Indicator
-  Fog Light Indicator*

System Indicators

-  Turn Signal and Hazard Warning Indicators
-  Electric Power Steering (EPS) System Indicator
-  Immobilizer System Indicator
-  Seat Belt Reminder Indicator
-  Supplemental Restraint System Indicator
-  Adaptive Cruise Control (ACC) Indicator (Amber/Green)
-  Road Departure Mitigation (RDM) Indicator
-  Collision Mitigation Braking System™ (CMBS™) Indicator
-  Lane Keeping Assist System (LKAS) Indicator (Amber/Green)
-  Auto High-Beam Indicator
-  All-Wheel Drive (AWD) System Indicator*

* Not available on all models

Eco Assist® System

Ambient Meter

The color of the ambient meter changes to green to indicate that the vehicle is being driven in a fuel efficient manner.

ECON Mode Indicator

Comes on when **ECON** button is pressed.



ECON Button

Helps maximize fuel economy.



Models with multi-information display

The message is displayed for a few seconds when the **ECON** button is pressed.

