


Use the audio/information screen to customize certain features.

■ How to customize

With the power mode in ON, select **Settings**, then select a setting item.



▶ Customized Features

When you customize settings:

- Make sure that the vehicle is at a complete stop.
- Shift to **P**.


To customize features detail, refer to the following.

- ▶ **Customization flow** P. 352
- ▶ **List of customizable options** P. 358

■ Customization flow

Press the  button.

Select **Settings**.



Features

System

Day & Time

Set Date & Time

Automatic Date & Time

Set Date

Set Time

Time Zone

Automatic Time Zone*

(Select time zone)

Auto Daylight Saving Time

Date Format

Time Format

Language

Touch Panel Sensitivity

System Volumes

System Volumes

Reading/Warning

Verbal Reminder

Config. of Instrument Panel


Select configuration


Security

Password

Unknown sources

* Not available on all models







*1 : Models with wireless Apple CarPlay and wireless Android Auto

*2 : Models without wireless Apple CarPlay and wireless Android Auto


* Not available on all models



* Not available on all models



* Not available on all models



* Not available on all models

■ List of customizable options

| Setup Group | Customizable Features | | Description | Selectable Settings |
|-------------|-----------------------|----------------------------------|--|--|
| System | Day & Time | Automatic Date & Time | Selects ON to have the GPS automatically adjust the clock. Select OFF to cancel this function. | ON*¹/OFF |
| | | Set Date & Time | | |
| | | Set Date | Adjusts date. ▶ Adjusting the Clock P. 166 | — |
| | | Set Time | Adjusts clock. ▶ Adjusting the Clock P. 166 | — |
| | | Time Zone | | |
| | | Automatic Time Zone* | Sets the navigation system to automatically adjust the clock when driving through different time zones. | ON*¹/OFF |
| | | (Select time zone) | Changes the time zone manually. | — |
| | | Auto Daylight Saving Time | Select ON to have the GPS automatically adjust the clock to daylight savings time. Select OFF to cancel this function. | ON*¹/OFF |
| | | Date Format | Sets the date format. | MM/DD/YYYY*¹/DD/MM/YYYY/YYYY/MM/DD |
| | | Time Format | Selects the digital clock display from 12H to 24H . | 12H*¹/24H |

*1:Default Setting

* Not available on all models

| Setup Group | Customizable Features | | Description | Selectable Settings |
|-------------|-----------------------------|---|---|---|
| System | Language | | Changes the display language. | English (United States)* ¹ /Español/ Français |
| | Touch Panel Sensitivity | | Sets the sensitivity of the touch panel screen. | High/Normal* ¹ |
| | System Volumes | System Volumes | Changes the system sounds volume. | — |
| | | Reading/ Warning Verbal Reminder | Turns the verbal reminders on and off. | ON* ¹ /OFF |
| | Config. of Instrument Panel | Select configuration | Selects whether the apps display comes on or not on the driver information interface. | Config.1* ¹ /Config.2/ Config.3 |
| | Security | Password | Set the value of password display. | ON* ¹ /OFF |
| | | Unknown sources | — | ON/OFF* ¹ |

*1:Default Setting

| Setup Group | Customizable Features | | Description | Selectable Settings |
|-------------|-----------------------|-------------------------------|------------------------------------|--|
| System | Accessibility | Caption | Turns the subtitles on and off. | ON/OFF*1 |
| | | Language | Change the subtitle language. | Default*1/English (United States)/Español/Français |
| | | Text Size | Change the subtitle Text Size. | Very small/Small/Normal*1/Large |
| | | Caption style | Change the subtitle Caption style. | Use app defaults*1/White on black/Black on white/Yellow on black/Yellow on blue/Custom |
| | Text-to-speech output | Current TTS engine TtsService | TtsService | — |

*1:Default Setting

| Setup Group | Customizable Features | | Description | Selectable Settings |
|-------------|-----------------------|-------------------------------|---|---------------------|
| System | Refuel recommend* | | Turns the refuel recommend function on and off. ▶ Refuel Recommend P. 400 | ON*1/OFF |
| | About | Status | Displays the Android setting items. | — |
| | | Legal Information | | |
| | Factory Data Reset | | Resets all the settings to their factory default. ▶ Defaulting All the Settings P. 370 | Continue/Cancel |
| | Detail Information | App Manager | Displays the Android system memory and apps information. | — |
| | | Recent Location Requests Apps | Displays the recent location requests from apps. | — |

*1:Default Setting

* Not available on all models

| Setup Group | Customizable Features | Description | Selectable Settings |
|-------------------------------------|-------------------------------------|--|--|
| Smartphone Connection ^{*2} | Apple CarPlay | + Connect New Device Pairs a new phone to Apple CarPlay. 📱 Phone Setup P. 379 | — |
| | | (Saved Devices) Connects, disconnects, or deletes a paired phone. 📱 Phone Setup P. 379 | — |
| | Android Auto | + Connect New Device Pairs a new phone to Android Auto. 📱 Phone Setup P. 379 | — |
| | | (Saved Devices) Connects, disconnects, or deletes a paired phone. 📱 Phone Setup P. 379 | — |
| Connections | Wi-Fi | Change Mode Changes the Wi-Fi mode. | Network^{*1}/Hotspot/ OFF |
| | | (Available Networks/ Connected Devices) Displays the available network(s) or current connected device(s). | — |
| | Bluetooth | + Connect New Device Pairs a new phone to HFL. 📱 Phone Setup P. 379 | — |
| | | (Saved Devices) Connects, disconnects, or deletes a paired phone. 📱 Phone Setup P. 379 | — |
| | Smartphone Connection ^{*3} | Apple CarPlay Sets up the Apple CarPlay connection. | — |
| | | Android Auto Sets up the Android Auto connection. | — |

*1:Default Setting

*2:Models with wireless Apple CarPlay and wireless Android Auto

*3:Models without wireless Apple CarPlay and wireless Android Auto

| Setup Group | Customizable Features | | Description | Selectable Settings |
|-------------|----------------------------|---------------------------------|--|--|
| Display | Day Mode | | Adjusts the settings of the audio/information screen. ▶ Display Setup P. 273 | — |
| | Night Mode | | | |
| Sound | Bass / Treble | Treble | Adjusts the settings of the audio speakers' sound. ▶ Adjusting the Sound P. 272 | — |
| | | Midrange | | |
| | | Bass | | |
| | | Subwoofer* | | |
| | Balance / Fader | | | |
| | DTS Neural Surround* | | | |
| | Speed Volume Compensation | | | |
| Vehicle | TPMS Calibration | | Cancels/Calibrates the tire pressure monitoring system (TPMS). | Calibrate/Cancel |
| | Driver Assist System Setup | Blind Spot Info* | Changes the setting for the blind spot information. | Audible And Visual Alert* ¹ /Visual Alert |
| | | Head-up Warning* | Turns the head-up warning on and off. | ON* ¹ /OFF |
| | | Traffic Sign Recognition System | Select On/Off to indicate small displaying traffic sign icon on the driver information interface and the head-up display*. | Small Icons ON* ¹ /Small Icons OFF |

*1:Default Setting

* Not available on all models

| Setup Group | Customizable Features | Description | Selectable Settings |
|-------------|---|---|--|
| Vehicle | Forward Collision Warning Distance | Changes Collision Mitigation Braking System™ (CMBST™) alert distance. | Normal^{*1}/Short/Long |
| | ACC Forward Vehicle Detect Beep | Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC with Low Speed Follow range. | ON/OFF^{*1} |
| | Driver Assist System Setup | | |
| | Lane Keeping Assist Suspend Beep | Causes the system to beep when Lane Keeping Assist System (LKAS) is suspended. | ON/OFF^{*1} |
| | Road Departure Mitigation Setting | Changes the setting for the road departure mitigation system. | Normal^{*1}/Wide/Warning Only/Narrow |
| | Driver Attention Monitor | Changes the setting for the driver attention monitor. | OFF/Tactile Alert/Tactile And Audible Alert^{*1} |
| | Language Selection | Changes the display language. | English^{*1}/Français/Español |
| | Meter Setup | | |
| | Adjust Outside Temp. Display | Adjusts the temperature reading by a few degrees. | -5°F ~ ±0°F^{*1} ~ +5°F (U.S.) -3°C ~ ±0°C^{*1} ~ +3°C (Canada) |
| | Rear Seat Reminder* | Turns the Rear Seat Reminder feature on and off. | ON^{*1}/OFF |
| | Adjust Alarm Volume | Changes the alarm volume, such as the buzzers, warnings, turn signal sound, and so on. | High/Mid^{*1}/Low |

*1: Default Setting

* Not available on all models

| Setup Group | | Customizable Features | Description | Selectable Settings |
|-------------|-------------|---|---|---|
| Vehicle | Meter Setup | Reverse Alert Tone* | Turns the reverse alert tone on and off. | ON* ¹ /OFF |
| | | Config. of Instrument Panel | Selects whether the apps display comes on or not on the driver information interface. | Config.1* ¹ /Config.2/ Config.3 |
| | | Fuel Efficiency Backlight | Turns the ambient meter feature on and off. | ON* ¹ /OFF |
| | | “Trip A” Reset Timing | Changes the setting of how to reset trip meter A and average fuel economy A. | When Fully Refueled/Manually Reset* ¹ /IGN OFF |
| | | “Trip B” Reset Timing | Changes the setting of how to reset trip meter B and average fuel economy B. | When Fully Refueled/Manually Reset* ¹ /IGN OFF |
| | | Auto Engine Idle Stop Guidance Screens* | Selects whether the Auto Idle Stop display comes on or not. | ON* ¹ /OFF |
| | | Tachometer | Selects whether the tachometer come on the driver information interface. | ON/OFF* ¹ |
| | | Speed/Distance Units | Selects the trip computer units. | km/h · km/mph · miles* ¹ (U.S.) km/h · km* ¹ /mph · miles (Canada) |

*1:Default Setting

* Not available on all models

| Setup Group | Customizable Features | | Description | Selectable Settings |
|-------------|-------------------------------------|--------------------------------------|---|---|
| Vehicle | Meter Setup | Turn By Turn Auto Display | Selects whether the turn-by-turn display comes on during the route guidance. | ON ^{*1} /OFF |
| | Driving Position Setup [*] | Memory Position Link | Turns the driving position memory system on and off. | ON ^{*1} /OFF |
| | | Seat Position Movement at Entry/Exit | Moves the seat rearward when you get in/get out of the vehicle. Changes the setting for this feature. | ON ^{*1} /OFF |
| | Keyless Access Setup [*] | Door Unlock Mode | Changes which doors unlock when you grab the driver's door handle. | Driver Door Only ^{*1} / All Doors |
| | | Smart Entry Light Flash | Causes some exterior lights to flash when you unlock/lock the doors. | ON ^{*1} /OFF |
| | | Smart Entry Beep | Causes the beeper to sound when you unlock/lock the doors. | ON ^{*1} /OFF |
| | | Remote Start System ON/OFF | Turns the remote engine start feature on and off. | ON ^{*1} /OFF |

^{*1}:Default Setting

^{*} Not available on all models

| Setup Group | Customizable Features | Description | Selectable Settings |
|-------------|-----------------------|---|--|
| Vehicle | Lighting Setup | Headlight Auto OFF Timer | Changes the length of time the exterior lights stay on after you close the driver's door. 0 sec/15 sec^{*1}/30 sec/60 sec |
| | | Interior Light Dimming Time | Changes the length of time the interior lights stay on after you close the doors. 15 sec/30 sec^{*1}/60 sec |
| | | Auto Light Sensitivity[*] | Changes the timing for the headlights to come on. Min/Low/Mid^{*1}/High/Max |
| | | Auto Interior Illumination Sensitivity | Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in AUTO . Min/Low/Mid^{*1}/High/Max |
| | | Auto Headlight On with Wiper On | Used to automatically come on the headlights when the wipers are used several times within a certain number of intervals with the headlight switch is in AUTO . ON^{*1}/OFF |

*1:Default Setting

* Not available on all models

| Setup Group | Customizable Features | Description | Selectable Settings | |
|-------------|-----------------------|----------------------------------|---|---|
| Vehicle | Door/Window Setup | Auto Door Lock | Changes the setting for the automatic locking feature. | OFF/With Vehicle Speed ^{*1} /Shift From P |
| | | Key and Remote Unlock Mode | Sets up either the driver's door or all doors to unlock on the first push of the keyless remote or built-in key. | Driver Door Only ^{*1} / All Doors |
| | | Keyless Lock Answer Back | LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds. | ON ^{*1} /OFF |
| | | Security Relock Timer | Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door. | 30sec ^{*1} /60sec/90sec |
| | | Auto Door Unlock | Changes the setting for when the doors unlock automatically. | OFF/All Doors When Driver's Door Opens ^{*1} /All Doors When Shifted to Park/All Doors With IGN OFF |
| | | Walk Away Auto Lock [*] | Changes the settings for the auto lock function when you walk away from the vehicle. | ON/OFF ^{*1} |
| | Maintenance Info. | Select Reset Items | Resets the engine oil life display when you have performed the maintenance service. | — |

*1:Default Setting

* Not available on all models

| Setup Group | Customizable Features | Description | Selectable Settings |
|-------------|-------------------------------|---|---------------------|
| Camera | Rear Camera | Fixed Guideline Selects whether the guidelines come on the rear camera monitor. ▶ Multi-View Rear Camera P. 529 | ON*1/OFF |
| | | Dynamic Guideline Selects whether the guidelines come on the rear camera monitor. ▶ Multi-View Rear Camera P. 529 | ON*1/OFF |
| | Cross Traffic Monitor* | Turns the cross traffic monitor on and off. | ON*1/OFF |


*1:Default Setting


* Not available on all models

Defaulting All the Settings


Reset all the menu and customized settings as the factory defaults.


Defaulting System Settings



1. Press the  button.
2. Select **Settings**.
3. Select **System**.
4. Select **Factory Data Reset**.
 - A confirmation message appears on the screen.
5. Select **Continue** to reset the settings.
6. Select **Continue** again to reset the settings.
 - The system will reboot.

Defaulting Vehicle Settings




1. Press the  button.
2. Select **Settings**.
3. Select **Vehicle**.
4. Select **Default**.
5. Select **Yes**.

Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

If you perform **Factory Data Reset**, it will reset the preinstalled apps to their factory default.

If you perform **Factory Data Reset**, you cannot use the HondaLink® because it goes offline.

 **HondaLink®** P. 301

The HomeLink® Universal Transceiver can be programmed to operate up to three remote controlled devices around your home, such as garage doors, lighting, or home security systems.

■ Important Safety Precautions

Refer to the safety information that came with your garage door opener to test that the safety features are functioning properly. If you do not have the safety information, contact the manufacturer.

Before programming HomeLink, make sure that people and objects are out of the way of the garage or gate to prevent potential injury or damage.

When programming a garage door opener, park just outside the garage door's path.

» HomeLink® Universal Transceiver*

Before programming HomeLink to operate a garage door opener, confirm that the opener has an external entrapment protection system, such as an "electronic eye," or other safety and reverse stop features. If it does not, HomeLink may not be able to operate it.

NOTE:

Some LED lightbulbs installed in the garage door opener can interfere with the training and consistent operation of your HomeLink device. Please consider use of Low RF interference bulbs in your garage door opener.