To Set Up Text Message Options



- To turn on or off the text message notice
- 1. Press the 👧 button.
- 2. Select Messages.
- 3. Select Settings.
- 4. Select Pop-up Notification.
- 5. Select ON or OFF.

➢To Set Up Text Message Options

To use the text message function, it may be necessary to set up on your phone.

≥To turn on or off the text message notice

ON: A pop-up notification comes on every time you receive a new message.

OFF: The message you receive is stored in the system without notification.

Receiving a Text Message

HFL can display newly received text messages as well as the last 20 messages received on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase.



- 1. Select the system status icon.
- The status area appears.
- **2.** A pop-up appears and notifies you of a new text message.
- 3. Select Open to display the message.The text message is displayed.
- Select Play to listen to the message. To discontinue the message read-out, select Stop.

Receiving a Text Message

Some cell phones might not be able to read the transmission log of data sent and data received.

The system does not display any received messages while you are driving. You can only hear them read aloud.

The system can only receive messages that are sent as text (SMS) messages. The message sent using the data services will not be displayed in the list.

With some phones, you may be able to display up to 20 of the last text messages received.

State or local laws may limit your use of the HFL text message feature. Only use the text message feature when conditions allow you to do so safely.

Selecting a Phone

You can select one from the *Bluetooth*[®] device list to be active and receive notifications.



- 1. Press the 👧 button.
- 2. Select Messages.
- 3. Select Settings.
- 4. Select Change Connected Phone.
- **5.** Change a desired phone.

To change the currently paired phone P. 388

Selecting a Phone

You can only receive notifications from one phone at a time.

Displaying Messages



- 1. Press the 🔝 button.
- 2. Select Messages.
 - Select a phone if necessary.
- 3. Select a message.
 - ► The text message is displayed.

➢Displaying Messages

The \bigcap (blue) icon appears next to an unread message.

If you delete a message on the phone, the message will also be deleted from the system. If you send a message from the system, the message goes to your phone's outbox.

To see the previous or next message, select **Prev.** or **Next >** on the message screen.





Read or Stop reading a message

- 1. Go to the text message screen.
- 2. Select Play.
- The system starts reading the message aloud.
- Select Stop to stop reading. Select Play again to start reading the message.

Reply to a message

- 1. Go to the text message screen.
- 2. Select Reply.
- **3.** Select the reply message.
 - ▶ The pop-up menu appears on the screen.
- 4. Select Send to send the message.
 - Message sent. appears on the screen when the reply message was successfully sent.

Reply to a message

The available fixed reply messages are as follows:

- Talk to you later, I'm driving.
- I'm on my way.
- I'm running late.
- OK
- Yes
- No

The default reply messages are displayed only in English. If you want to use reply messages in languages other than English, please edit them.

To edit a reply message P. 403

You can add a reply message by selecting + Create New Message.

To edit a reply message P. 403

Only certain phones receive and send messages when paired and connected. For a list of compatible phones:

- U.S.: Visit automobiles.honda.com/handsfreelink/, or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-855-490-7351.

Features



Phone		12:34
)	≫ Delete Replies	
	Talk to you later, I'm driving.	
	I'm on my way.	
	I'm running late.	
	ОК	
¥	Yes	

To edit a reply message

- 1. Press the 🔝 button.
- 2. Select Messages.
- 3. Select Settings.
- 4. Select Edit Replies.
- 5. Select the reply message you want to edit
 - or + Create New Message.
 - The on-screen keyboard screen is displayed.
- 6. Enter a reply message, and then select Save.
- To delete a reply message
- 1. Press the 🟦 button.
- 2. Select Messages.
- 3. Select Settings.
- 4. Select Delete Replies.
- Select
 on the reply message you want to delete.
 - ▶ The pop-up menu appears on the screen.
- 6. Select Yes.

■To edit a reply message

You can change the order of reply messages by selecting **Reorder**.



Making a call to a sender

1. Go to the text message screen.

2. Select Call.