



# Customized Features

## Models with Display Audio

Use the audio/information screen to customize certain features.

### ■ How to customize

While the vehicle is at a complete stop with the power mode in ON, select , and **Settings**, then select a setting item.




## Customized Features

When you customize settings:

- Make sure that the vehicle is at a complete stop.
- Shift to **P**.

Continued


## ■ Customization flow




\*1: Does not appear when you change the screen interface design.


\*2: Appears only when you change the screen interface design.

\* Not available on all models






\* Not available on all models



\*1: Does not appear when you change the screen interface design.


\*2: Appears only when you change the screen interface design.




\*1: Does not appear when you change the screen interface design.

\*2: Appears only when you change the screen interface design.


\* Not available on all models



\*1: Does not appear when you change the screen interface design.







Features

■ List of customizable options

Setup Group	Customizable Features		Description	Selectable Settings
Clock	Clock	Clock/ Wallpaper Type <sup>*1</sup> /Clock Type <sup>*2</sup>	Clock	
			Wallpaper	
		Clock Adjustment		
		Auto Time Zone <sup>*</sup>		
		Manual Time Zone <sup>*</sup>		
		Auto Daylight Saving Time		
		Clock Format		
		Clock Display		
		Overlay Clock Location		
		Clock Reset		
	HondaLink	Diagnostic & Location Data		
	Others	Info Screen Preference		
Default			Cancels/Resets all customized items in the Clock settings group as default.	Yes/No

\*1: Does not appear when you change the screen interface design.

\*2: Appears only when you change the screen interface design.

\* Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings
Info	Clock	<b>Clock/ Wallpaper Type<sup>*2/</sup> Clock Type<sup>*3</sup></b>	<b>Clock</b>  Changes the clock display type.	<b>Analog/Digital<sup>*1/</sup> Small Digital/Off</b>
			<b>Wallpaper</b>  <ul style="list-style-type: none"> <li>Changes the wallpaper type.</li> <li>Imports an image file for a new wallpaper.</li> <li>Deletes an image file for a wallpaper.</li> </ul>	<b>Blank/Galaxy<sup>*1/</sup> Metallic/Time Zone</b>
		<b>Clock Adjustment</b>	Adjusts Clock.	—
		<b>Auto Time Zone<sup>*</sup></b>	Automatically adjusts the clock when driving through different time zones.	<b>On<sup>*1/</sup>Off</b>
		<b>Manual Time Zone<sup>*</sup></b>	Changes the time zone manually.	—
		<b>Auto Daylight Saving Time</b>	Select <b>On</b> to have the GPS automatically adjust the clock to daylight savings time. Select <b>Off</b> to cancel this function.	<b>On<sup>*1/</sup>Off</b>
		<b>Clock Format</b>	Selects the digital clock display from 12H to 24H.	<b>12H<sup>*1/</sup>24H</b>
		<b>Clock Display</b>	Selects whether the clock display comes on.	<b>On<sup>*1/</sup>Off</b>
		<b>Overlay Clock Location</b>	Changes the clock display layout.	<b>Upper Right<sup>*1/</sup>Upper Left/Lower Right/ Lower Left/Off</b>
		<b>Clock Reset</b>	Resets the clock settings to the factory default.	<b>Yes/No</b>




\*1:Default Setting

\*2:Does not appear when you change the screen interface design.

\*3:Appears only when you change the screen interface design.

\* Not available on all models

Continued

Setup Group	Customizable Features		Description	Selectable Settings
Info	HondaLink	<b>Diagnostic &amp; Location Data</b>	Turns HondaLink® on and off.	<b>On*<sup>1</sup>/Off</b>
	Others	<b>Info Screen Preference</b>	Selects the top menu when the  (display/information) button is pressed. <ul style="list-style-type: none"> <li>• <b>Info Top</b>- A brief menu pops up.</li> <li>• <b>Info Menu</b>- A full menu pops up.</li> <li>• <b>Off</b>- A menu does not pop up.</li> </ul>	<b>Info Top/Info Menu*<sup>1</sup>/Off</b>
	<b>Default</b>		Cancels/Resets all customized items in the <b>Info</b> settings group as default.	<b>Yes/No</b>
	Camera	<b>Fixed Guideline</b>	Selects whether the fixed guidelines come on the rear camera monitor.  <b>Multi-View Rear Camera</b> P. 556	<b>On*<sup>1</sup>/Off</b>
		<b>Dynamic Guideline</b>	Selects whether the guidelines adjust to the movement of the steering wheel.  <b>Multi-View Rear Camera</b> P. 556	<b>On*<sup>1</sup>/Off</b>
		<b>Default</b>	Cancels/Resets all customized items in the <b>Rear Camera</b> setting group as default.	<b>Yes/No</b>
		<b>Show with Turn Signal</b>	Selects whether the LaneWatch display comes on when you move the turn signal lever to indicate a right turn.	<b>On*<sup>1</sup>/Off</b>
		<b>Display Time after Turn Signal Off</b>	Changes the length of time the LaneWatch display stays on after the turn signal lever returns to the center.	<b>0 second*<sup>1</sup>/2 seconds</b>

\*1:Default Setting

\* Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings	
Camera	LaneWatch*	Reference Line	Selects whether the reference lines come on the LaneWatch monitor.	On*/Off	
		Default	Cancels/Resets all customized items in the <b>LaneWatch</b> group as default.	Yes/No	
	Cross Traffic Monitor*		Turns on and off the cross traffic monitor.	On*/Off	
Bluetooth / Wi-Fi	Bluetooth	Bluetooth On/Off Status	Changes the <i>Bluetooth</i> ® status.	On*/Off	
		Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone. 🔧 Phone Setup P. 427	—	
		Priority Device Settings	Priority On/Off Status	Enables the system to or disables it from automatically establishing a connection with a <i>Bluetooth</i> ® device which has been assigned priority.	On*/Off
			Audio	Selects the priority device over another paired audio device(s).	—
			Phone	Selects the priority device over another paired phone(s).	—
		Edit Pairing Code		Edits a pairing code. 🔧 To change the pairing code setting P. 428	Random/Fixed* <sup>1</sup>

\*1:Default Setting

\* Not available on all models

Continued

Setup Group	Customizable Features	Description	Selectable Settings
<b>Bluetooth / Wi-Fi</b>	<b>Wi-Fi On/Off Status</b>	Changes the Wi-Fi mode.	<b>On/Off</b> *1
	<b>Wi-Fi Device List</b>	Connects, disconnects, or deletes the Wi-Fi device.	—
	<b>Wi-Fi Information</b>	Shows the Wi-Fi information of the head unit.	—
	<b>Default</b>	Cancels/Resets all customized items in the <b>Bluetooth / Wi-Fi</b> group as default.	<b>Yes/No</b>
<b>Phone</b>	<b>Bluetooth Device List</b>	Pairs a new phone to HFL, connects or disconnects a paired phone. 📱 <b>Phone Setup</b> P. 427	—
	<b>Edit Speed Dial</b>	Edits, adds or deletes a speed dial entry. 📞 <b>Speed Dial</b> P. 433	—
	<b>Ring Tone</b>	Selects the ring tone.	<b>Fixed/Mobile Phone</b> *1
	<b>Automatic Phone Sync</b>	Sets a phonebook and call history data to be automatically imported when a phone is paired to HFL.	<b>On</b> *1/ <b>Off</b>
	<b>HondaLink Assist</b>	Turns HondaLink Assist on and off.	<b>On</b> *1/ <b>Off</b>

\*1: Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Phone	Text/Email	Enable Text/Email	Turns the text/e-mail message function on and off.	On <sup>*1</sup> /Off
		Select Account	Selects a text or e-mail message account.	—
		New Message Notification	Selects whether a pop-up alert comes on the screen when HFL receives a new text/e-mail message.	On/Off <sup>*1</sup>
	Default		Cancels/Resets all customized items in the <b>Phone</b> settings group as default.	Yes/No
Audio	FM/AM mode FM/AM	HD Radio Mode (FM) <sup>*</sup> HD Radio Mode (AM) <sup>*</sup>	Selects whether the audio system automatically switches to the digital radio waves or receives the analog waves only.	Auto <sup>*1</sup> /Analog only
		RDS INFO	Turns on and off the RDS information.	On <sup>*1</sup> /Off

\*1: Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Audio	SiriusXM® mode SXM*	TuneStart	Turns on and off, starts the song from the beginning as you change preset stations.	On* <sup>1</sup> /Off
		Interrupt	Turns on and off the sports alert function.	Off* <sup>1</sup> /On(One Time)/ On(Continue)
		SportsFlash Setup	Favorite Team Selects your favorite sports teams. 📺 Live Sports Alert P. 305	—
		Interrupt Beep	Causes the system to beep when the sports alert is notified.	On* <sup>1</sup> /Off
		Traffic & Weather Setup	Selects the region you want to receive the information.	—
		Multiple Channel Mix Preset	Turns multiple channel mix preset on and off.	On* <sup>1</sup> /Off

\*1:Default Setting

\* Not available on all models



Setup Group	Customizable Features		Description	Selectable Settings
Audio	Bluetooth	<b>Bluetooth® mode</b> <b>Bluetooth Device List</b>	Pairs a new phone to HFL, edits or deletes a paired phone. 📱 <b>Phone Setup</b> P. 427	—
		<b>iPod or USB mode</b> [Your selected media] <b>Cover Art</b>	Turns the cover art display on and off.	<b>On</b> * <sup>1</sup> / <b>Off</b>
	Other	<b>Audio Source Pop-Up</b>	Selects whether the list of selectable audio source comes on when <b>Audio</b> is selected on the home screen.	<b>On/Off</b> * <sup>1</sup>
		<b>Default</b>	Cancels/Resets all customized items in the <b>Audio</b> settings group as default.	<b>Yes/No</b>
System	Home	<b>Home Screen Edit Order</b>	Changes the home screen icon layout.	—
		<b>Menu Icon Position</b> * <sup>2</sup>	Changes the position of the menu icons on the <b>Audio</b> , <b>Phone</b> , and <b>Info</b> screen.	—
		<b>Configuration of Instrument Panel</b>	Changes the <b>Instrument Panel</b> screen icon layout.	—
		<b>Tachometer Setting</b>	Turns on and off the tachometer display.	<b>On</b> * <sup>1</sup> / <b>Off</b>




\*1:Default Setting

\*2:Appears only when you change the screen interface design.

Setup Group	Customizable Features	Description	Selectable Settings
System	Display	<b>Brightness</b>	Changes the brightness of the audio/information screen. —
		<b>Contrast</b>	Changes the contrast of the audio/information screen. —
		<b>Black Level</b>	Changes the black level of the audio/information screen. —
		<b>Background Color</b> <sup>*2</sup>	Changes the background color of the audio/information screen. <b>Blue/Amber/Red/Violet/BlueGreen</b> <sup>*1</sup>
	Sound/Beep	<b>Touch Panel Sensitivity</b>	Sets the sensitivity of the touch panel screen. <b>High/Low</b> <sup>*1</sup>
		<b>Guidance Volume</b>	Changes the sound volume. Adjusts the guidance volume of the navigation system. <b>1~6</b> <sup>*1</sup> ~ <b>11</b>
		<b>Text Message Volume</b>	Changes the text/e-mail message reading volume. <b>1~6</b> <sup>*1</sup> ~ <b>11</b>

\*1: Default Setting

\*2: Does not appear when you change the screen interface design.

Setup Group	Customizable Features	Description	Selectable Settings
System	Sound/ Beep	<b>Voice Recog. Volume</b>	Changes the volume of the voice prompt. <b>1~6<sup>*1</sup>~11</b>
		<b>Meter Volume - List Reading</b>	Changes the list reading volume. <b>1~6<sup>*1</sup>~11</b>
		<b>Meter Volume - Alphabetic Reading</b>	Changes the alphabetic reading volume. <b>1~6<sup>*1</sup>~11</b>
		<b>Verbal Reminder</b>	Turns the verbal reminders on and off. <b>On<sup>*1</sup>/Off</b>
		<b>Beep Volume</b>	Changes the beep volume. <b>Off/1/2<sup>*1</sup>/3</b>
	Voice Recog.	<b>One Press Voice Operation</b>	Changes the setting of the  (Talk) button operation when using the voice operation. <b>On<sup>*1</sup>/Off</b>
		<b>Voice Prompt</b>	Turns the voice prompt on and off. <b>On<sup>*1</sup>/Off</b>
		<b>Voice Recog. Volume</b>	Changes the volume of the voice prompt. <b>1~6<sup>*1</sup>~11</b>
		<b>Song by Voice</b>	Turns the Song By Voice™ on and off. <b>On<sup>*1</sup>/Off</b>
		<b>Song by Voice Phonetic Modification</b>	Modifies a voice command for music stored in the system or an iPod/iPhone. —  <b>Phonetic Modification</b> P. 312
		<b>Phonebook Phonetic Modification</b>	Modifies a voice command for the phonebook. —  <b>Phonetic Modification</b> P. 312
		<b>Automatic Phone Sync</b>	Sets phonebook and call history data to be automatically imported when a phone is paired to HFL. <b>On/Off</b>

\*1: Default Setting

Continued

Setup Group	Customizable Features		Description	Selectable Settings
System	Clock	<b>Clock/Wallpaper Type<sup>*2</sup>/Clock Type<sup>*3</sup></b>	<b>Clock</b>	
			<b>Wallpaper</b>	
		<b>Clock Adjustment</b>		
		<b>Auto Time Zone<sup>*</sup></b>		
		<b>Manual Time Zone<sup>*</sup></b>		
		<b>Auto Daylight Saving Time</b>		
		<b>Clock Format</b>		
		<b>Clock Display</b>		
		<b>Overlay Clock Location</b>		
		<b>Clock Reset</b>		
	Others	<b>Language</b>	Change the display language.	<b>English (United States)<sup>*1</sup>/Français/Español</b>
		<b>Voice Command Tips</b>	Alerts you when manual control of the system is disabled to prevent distraction while driving. Only voice commands are available.	<b>On<sup>*1</sup>/Off</b>

\*1: Default Setting

\*2: Does not appear when you change the screen interface design.

\*3: Appears only when you change the screen interface design.

\* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
<b>System</b>	<b>Remember Last Screen</b> *2	Selects whether the device remembers the last screen.	<b>On/Off</b> *1
	<b>Memory Refresh</b>	Turns on the audio system automatically and restores the fragmentation of a memory when the power mode is VEHICLE OFF (LOCK).	<b>On</b> *1/ <b>Off</b>
	<b>Refresh Time Adjustment</b>	Sets the time for <b>Memory Refresh</b> .	—
	<b>Change Skin</b>	Changes the screen interface design.	<b>Yes/No</b>
	<b>Factory Data Reset</b>	Resets all the settings to their factory default. 🔧 <b>Defaulting All the Settings</b> P. 391	<b>Yes/No</b>
	<b>Climate Screen Timeout</b>	Changes the length of time the climate control display stays on when you press the <b>CLIMATE</b> button.	<b>Never/5 Seconds/10 Seconds</b> *1/ <b>20 Seconds</b>
	<b>Detail Information</b>	Displays the details of the head unit and operating system information.	—
	<b>Default</b>	Cancels /Resets all customized items in the <b>System</b> group as default.	<b>Yes/No</b>

\*1:Default Setting

\*2:Does not appear when you change the screen interface design.

Setup Group	Customizable Features	Description	Selectable Settings
Vehicle	Driver Assist System Setup	<b>TPMS Calibration</b>	Cancels/Calibrates the tire pressure monitoring system (TPMS). <b>Cancel<sup>*1</sup>/Calibrate</b>
		<b>Forward Collision Warning Distance</b>	Changes CMBS™ alert distance. <b>Long/Normal<sup>*1</sup>/Short</b>
		<b>ACC Forward Vehicle Detect Beep</b>	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC with Low Speed Follow range. <b>On/Off<sup>*1</sup></b>
		<b>Blind Spot Info</b>	Changes the setting for the blind spot information. <b>Audible and Visual Alert<sup>*1</sup>/Visual Alert/Off</b>
		<b>Lane Keeping Assist Suspend Beep</b>	Causes the system to beep when LKAS is suspended. <b>On/Off<sup>*1</sup></b>
		<b>Road Departure Mitigation Setting</b>	Changes the setting for the road departure mitigation system. <b>Narrow/Normal<sup>*1</sup>/Wide/Warning Only</b>
		<b>Driver Attention Monitor</b>	Changes the setting for the driver attention monitor. <b>Tactile And Audible Alert<sup>*1</sup>/Tactile Alert/Off</b>

\*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Vehicle Meter Setup	<b>Adjust Outside Temp. Display</b>	Adjusts the temperature reading by a few degrees.	-5°F ~ ±0°F* <sup>1</sup> ~ +5°F (U.S.) -3°C ~ ±0°C* <sup>1</sup> ~ +3°C (Canada)
	<b>"Trip A" Reset Timing</b>	Changes the setting of how to reset trip meter A and average fuel economy A.	<b>When Refueled/IGN Off/Manually Reset</b> * <sup>1</sup>
	<b>"Trip B" Reset Timing</b>	Changes the setting of how to reset trip meter B and average fuel economy B.	<b>When Refueled/IGN Off/Manually Reset</b> * <sup>1</sup>
	<b>Adjust Alarm Volume</b>	Changes the alarm volume, such as buzzers, warnings, turn signal sound, and so on.	<b>High/Mid</b> * <sup>1</sup> / <b>Low</b>
	<b>Fuel Efficiency Backlight</b>	Turns the ambient meter feature on and off.	<b>On</b> * <sup>1</sup> / <b>Off</b>
	<b>Auto Idle Stop Display</b>	Selects whether the Auto Idle Stop display comes on.	<b>On/Off</b> * <sup>1</sup>
	<b>Turn By Turn Auto Display*</b>	Selects whether the turn-by-turn display comes on during the route guidance.	<b>On</b> * <sup>1</sup> / <b>Off</b>
	<b>New Message Notifications</b>	Used to select whether a pop-up alert comes on the screen when HFL receives a new text/e-mail message.	<b>On</b> * <sup>1</sup> / <b>Off</b>
	<b>Speed/Distance Units</b>	Selects the trip computer units.	<b>mph · miles</b> * <sup>1</sup> / <b>km/h · km</b> (U.S.) <b>km/h · km</b> * <sup>1</sup> / <b>mph · miles</b> (Canada)

\*1: Default Setting

\* Not available on all models

Continued

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle	Meter Setup	Tachometer	Selects whether the tachometer come on the driver information interface.	On <sup>*1</sup> /Off
	Driving Position Setup <sup>*</sup>	Memory Position Link	Turns the driving position memory system on and off.	On <sup>*1</sup> /Off
	Keyless Access Setup	Remote Start System On/Off	Turns the remote engine start feature on and off.	On <sup>*1</sup> /Off
		Door Unlock Mode	Changes which doors unlock when you grab the driver's door handle.	Driver Door Only <sup>*1</sup> /All Doors
		Keyless Access Light Flash	Causes some exterior lights to flash when you unlock/lock the doors.	On <sup>*1</sup> /Off
		Keyless Access Beep	Causes the beeper to sound when you unlock/lock the doors.	On <sup>*1</sup> /Off
	Lighting Setup	Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	60seconds/30seconds <sup>*1</sup> /15seconds
		Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60seconds/30seconds/15seconds <sup>*1</sup> /0seconds
		Auto Light Sensitivity <sup>*</sup>	Changes the timing for the headlights to come on.	Max/High/Mid <sup>*1</sup> /Low/Min

\*1:Default Setting

\* Not available on all models



Setup Group	Customizable Features	Description	Selectable Settings
Vehicle	Lighting Setup	<b>Auto Interior Illumination Sensitivity</b>	Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in the <b>AUTO</b> position.
		<b>Auto Headlight ON With Wiper ON</b>	Changes the settings for the wiper operation when the headlights automatically come on while the headlight switch is in the <b>AUTO</b> position.
	Door/ Window Setup	<b>Auto Door Lock</b>	Used to change the setting for when the doors automatically lock.
		<b>Auto Door Unlock</b>	Changes the setting for when the doors unlock automatically.
		<b>Key and Remote Unlock Mode</b>	Sets up the driver's door or all the doors to unlock on the first push of the remote.
		<b>Keyless Lock Answer Back</b>	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.
		<b>Security Relock Timer</b>	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.

\*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle	Door/ Window Setup	<b>Walk Away Auto Lock</b>	Changes the settings for the auto lock function when you walk away from the vehicle.	<b>On/Off</b> *1
		<b>Hands-free Access Mode*</b>	Changes the setting to open power tailgate by a swift forward in and out kicking motion under the rear bumper.	<b>On*/Off</b>
	Power Tailgate Setup*	<b>Keyless Open Mode</b>	Changes the keyless setting for when the power tailgate opens.	<b>Anytime</b> *1/ <b>When Unlocked</b>
		<b>Power Open By Outer Handle</b>	Changes the setting to open power tailgate by tailgate outer handle.	<b>Off (Manual only)/ On (Power/ Manual)</b> *1
	<b>Maintenance Info.</b>		Used to reset the engine oil life display when the maintenance service has been performed.	—
	<b>Default</b>		Cancels/Resets all customized items in the Vehicle settings group as default.	<b>Yes/No</b>
Smartphone	<b>Apple CarPlay</b>		Sets up the Apple CarPlay™ connection.	—
	<b>Android Auto</b>		Sets up the Android Auto™ connection.	—


\*1:Default Setting


\* Not available on all models

## Models with Display Audio

## Defaulting All the Settings

Reset all the menu and customized settings as the factory defaults.



1. Select .
2. Select **Settings**.
3. Select **System**.
4. Select the **Others** tab.
5. Select **Factory Data Reset**.
  - A confirmation message appears on the screen.
6. Select **Next**, then select **Yes** to reset the settings.
7. Select **Yes** again to reset the settings.
  - A confirmation message appears on the screen. Select **OK**.
  - After selecting **OK**, the system will reboot.

### » Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

If you perform **Factory Data Reset**, it will reset the preinstalled apps to their factory default.

If you perform **Factory Data Reset**, you cannot use the HondaLink® because it becomes off line.

📄 **HondaLink®** P. 322