Models with Display Audio

Use the audio/information screen to customize certain features.

How to customize

While the vehicle is at a complete stop with the power mode in ON, select **fine**, and **Settings**, then select a setting item.



Customized Features

When you customize settings, make sure that the vehicle is at a complete stop and put the transmission into $[\mathbf{P}]$.

To customize features detail, refer to the following. Customization flow P. 370 List of customizable options P. 378 Customization flow



*1: Does not appear when you change the screen interface design.

*2: Appears only when you change the screen interface design.







*1: Does not appear when you change the screen interface design.

*2: Appears only when you change the screen interface design.



*1: Does not appear when you change the screen interface design.

*2: Appears only when you change the screen interface design.



*1: Does not appear when you change the screen interface design.





List of customizable options

Setup Group	Customizable Features		ures	Description	Selectable Settings
		Clock/	Clock		
		Wallpaper Type*1/Clock Type*2	Wallpaper		
		Clock Adjustm	ent		
		Auto Time Zone		-	
	Clock	Manual Time Zone			
		Auto Daylight Saving Time		See Info on P. 379	
Clock		Clock Format			
		Clock Display		-	
		Overlay Clock	Location	-	
		Clock Reset		-	
	HondaLink	Diagnostic & L	ocation Data		
	Others	Info Screen Pr	eference		
	Default	Default		Cancels/Resets all customized items in the Clock settings group as default.	Yes/No

*1:Does not appear when you change the screen interface design. *2:Appears only when you change the screen interface design.

Setup Group		Customizable Features		Description	Selectable Settings
		Clock/ Wallpaper	Clock	Changes the clock display type.	Analog/Digital ^{*1/} Small Digital/Off
		Type ^{*2/} Clock Type ^{*3}	Wallpaper	 Changes the wallpaper type. Imports an image file for a new wallpaper. Deletes an image file for a wallpaper. 	Blank/Galaxy ^{*1/} Metallic/Time Zone*
		Clock Adjustment Auto Time Zone		Adjusts Clock.	_
				Automatically adjusts the clock when driving through different time zones.	On ^{*1} /Off
Info (Clock	Manual Time	e Zone	Changes the time zone manually.	
ΙΠΤΟ	CIOCK	Auto Dayligh	nt Saving Time	Select On to have the GPS automatically adjust the clock to daylight savings time. Select Off to cancel this function.	On*1/Off
		Clock Format		Selects the digital clock display from 12H to 24H.	12H*1/24H
		Clock Display	y	Selects whether the clock display comes on.	On ^{*1} /Off
		Overlay Cloc	k Location	Changes the clock display layout.	Upper Right ^{*1/} Upper Left/Lower Right/ Lower Left/Off
		Clock Reset		Resets the clock settings to the factory default.	Yes/No

*2:Does not appear when you change the screen interface design. *3:Appears only when you change the screen interface design.

* Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings
Info	HondaLink	Diagnostic & Location Data	Turns HondaLink [®] on and off.	On ^{*1} /Off
	Others	Info Screen Preference	 Selects the top menu when the (display/information) button is pressed. Info Top- A brief menu pops up. Info Menu- A full menu pops up. Off- A menu does not pop up. 	Info Top/Info Menu*1/Off
	Default		Cancels/Resets all customized items in the Info settings group as default.	Yes/No
	Rear Camera	Fixed Guideline	Selects whether the fixed guidelines come on the rear camera monitor. Multi-View Rear Camera P. 570	On*1/Off
Comoro		Dynamic Guideline	Selects whether the guidelines adjust to the movement of the steering wheel. Multi-View Rear Camera P. 570	On*1/Off
Camera		Parking Sensor Display*	Selects whether to turn on the parking sensor display.	Normal View/Split View ^{*1}
		Default	Cancels/Resets all customized items in the Rear Camera setting group as default.	Yes/No
	Cross Traffic	Monitor	Turns on and off the cross traffic monitor.	On ^{*1} /Off

* Not available on all models

Setup Group	Cu	ustomizable Features		Description	Selectable Settings
		Bluetooth Or	n/Off Status	Changes the <i>Bluetooth</i> [®] status.	On ^{*1} /Off
	Bluetooth	Bluetooth Device List		Pairs a new phone to HFL, edits or deletes a paired phone. Paired Phone Setup P. 430	_
		Priority Device Settings	Priority On/ Off Status	Enables the system to or disables it from automatically establishing a connection with a <i>Bluetooth</i> [®] device which has been assigned priority.	On*1/Off
.			Audio	Selects the priority device over another paired audio device(s).	_
Bluetooth / Wi-Fi			Phone	Selects the priority device over another paired phone(s).	
		Edit Pairing Code		Edits a pairing code. To change the pairing code setting P. 431	Random/Fixed ^{*1}
		Wi-Fi On/Off	Status	Changes the Wi-Fi mode.	On/Off ^{*1}
	Wi-Fi	Wi-Fi Device	List	Connects, disconnects, or deletes the Wi-Fi device.	
		Wi-Fi Information		Shows the Wi-Fi information of the head unit.	
	Default			Cancels/Resets all customized items in the Bluetooth / Wi-Fi group as default.	Yes/No

Setup Group	Cu	stomizable Features	Description	Selectable Settings
		Bluetooth Device List	Pairs a new phone to HFL, connects or disconnects a paired phone. Phone Setup P. 430	—
		Edit Speed Dial	Edits, adds or deletes a speed dial entry. Speed Dial P. 436	_
	Phone	Ring Tone	Selects the ring tone.	Fixed/Mobile Phone ^{*1}
		Automatic Phone Sync	Sets a phonebook and call history data to be automatically imported when a phone is paired to HFL.	On*1/Off
Phone		HondaLink Assist	Turns HondaLink Assist on and off.	On*1/Off
		Enable Text/Email	Turns the text/e-mail message function on and off.	On*1/Off
	Text/Email	Select Account	Selects a text or e-mail message account.	—
		New Message Notification	Selects whether a pop-up alert comes on the screen when HFL receives a new text/e-mail message.	On/Off*1
	Default		Cancels/Resets all customized items in the Phone settings group as default.	Yes/No

Setup Group	Custo	omizable Featu	res	Description	Selectable Settings
	FM/AM mode FM/AM	HD Radio Mode (FM) HD Radio Mode (AM)		Selects whether the audio system automatically switches to the digital radio waves or receives the analog waves only.	Auto ^{*1} /Analog Only
		RDS INFO		Turns on and off the RDS information.	On ^{*1} /Off
		TuneStart		Turns on and off, starts the song from the beginning as you change preset stations.	On*1/Off
	SiriusXM® mode SXM		Interrupt	Turns on and off the sports alert function.	Off ^{*1/} On(One Time)/ On(Continue)
Audio			Favorite Team	Selects your favorite sports teams. Live Sports Alert P. 310	_
			Interrupt Beep	Causes the system to beep when the sports alert is notified.	On*1/Off
		Traffic & Weather Setup		Selects the region you want to receive the information.	_
		Multiple Channel Mix Preset		Turns multiple channel mix preset on and off.	On*1/Off

Setup Group	Customizable Features		Description	Selectable Settings
	<i>Bluetooth®</i> mode Bluetooth	Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone. Phone Setup P. 430	_
	Other	iPod or USB mode [Your selected media] Cover Art	Turns the cover art display on and off.	On*1/Off
Audio		Audio Source Pop-Up	Selects whether the list of selectable audio source comes on when Audio is selected on the home screen.	On/Off*1
	Sound		Adjusts the settings of the audio speakers' sound. Adjusting the Sound P. 294	—
	Default		Cancels/Resets all customized items in the Audio settings group as default.	Yes/No
		Home Screen Edit Order	Changes the home screen icon layout.	—
Sustam	Home	Menu Icon Position*2	Changes the position of the menu icons on the Audio , Phone , and Info screen.	—
System		Configuration of Instrument Panel	Changes the Instrument Panel screen icon layout.	—
		Tachometer Setting	Not available on this model	—

*1:Default Setting *2:Appears only when you change the screen interface design.

Setup Group	Customizable Features		eatures	Description	Selectable Settings
		Display Settings Y	Brightness	Changes the brightness of the audio/information screen.	—
	Display		Contrast	Changes the contrast of the audio/information screen.	—
			Black Level	Changes the black level of the audio/information screen.	—
System		Background Color*2		Changes the background color of the audio/ information screen.	Blue ^{*1} /Amber/Red/ Violet/BlueGreen
		Touch Pane	l Sensitivity	Sets the sensitivity of the touch panel screen.	High/Low ^{*1}
	Sound/ Beep	Guidance V	olume	Changes the sound volume. Adjusts the guidance volume of the navigation system.	1~6* ¹ ~11
		Text Messa	ge Volume	Changes the text/e-mail message reading volume.	1~6 ^{*1} ~11

*1:Default Setting *2:Does not appear when you change the screen interface design.

Setup Group	Customizable Features		Description	Selectable Settings
		Voice Recog. Volume	Changes the volume of the voice prompt.	1~6 ^{*1} ~11
		Meter Volume - List Reading	Changes the list reading volume.	1~6 ^{*1} ~11
	Sound/ Beep	Meter Volume - Alphabetic Reading	Changes the alphabetic reading volume.	1~6 ^{*1} ~11
		Verbal Reminder	Turns the verbal reminders on and off.	On ^{*1} /Off
		Beep Volume	Changes the beep volume.	Off/1/2*1/3
. .		One Press Voice Operation	Changes the setting of the <u>()</u> (Talk) button operation when using the voice operation.	On*1/Off
System		Voice Prompt	Turns the voice prompt on and off.	On ^{*1} /Off
		Voice Recog. Volume	Changes the volume of the voice prompt.	1~6 ^{*1} ~11
	Voice	Song by Voice	Turns the Song By Voice™ on and off.	On ^{*1} /Off
	Recog.	Song by Voice Phonetic Modification	Modifies a voice command for music stored in the system or an iPod/iPhone. Phonetic Modification P. 317	—
		Phonebook Phonetic Modification	Modifies a voice command for the phonebook. Phonetic Modification P. 317	_
		Automatic Phone Sync	Sets phonebook and call history data to be automatically imported when a phone is paired to HFL.	On/Off

Setup Group		Customizable Features		Description	Selectable Settings	
		Clock/Wallpaper	Clock			
		Type ^{*2} /Clock Type ^{*3}	Wallpaper			
		Clock Adjustment		-		
		Auto Time Zone				
	Clock	Manual Time Zone		See Info on P. 379		
		Auto Daylight Saving Time		-		
Guntaria		Clock Format Clock Display Overlay Clock Location				
System						
				_		
		Clock Reset				
	Others	Language		Change the display language.	English (United States)*1/Français/ Español	
		Voice Command Tips		Alerts you when manual control of the system is disabled to prevent distraction while driving. Only voice commands are available.	On*1/Off	

*2:Does not appear when you change the screen interface design. *3:Appears only when you change the screen interface design.

Features

Setup Group	C	ustomizable Features	Description	Selectable Settings
		Remember Last Screen*2	Selects whether the device remembers the last screen.	On/Off*1
		Memory Refresh	Turns on the audio system automatically and restores the fragmentation of a memory when the power mode is VEHICLE OFF (LOCK).	On*1/Off
		Refresh Time Adjustment	Sets the time for Memory Refresh .	—
	Others	hers Change Skin	Changes the screen interface design.	Yes/No
System		Factory Data Reset	Resets all the settings to their factory default. Defaulting All the Settings P. 394	Yes/No
		Climate Screen Timeout	Changes the length of time the climate control display stays on when you press the CLIMATE button.	Never/5 Seconds/10 Seconds*1/20 Seconds
		Detail Information	Displays the details of the head unit and operating system information.	_
	Default		Cancels /Resets all customized items in the System group as default.	Yes/No

*1:Default Setting *2:Does not appear when you change the screen interface design.

Setup Group	Customizable Features		Description	Selectable Settings	
	TPMS Calibration		Cancels/Calibrates the tire pressure monitoring system (TPMS).	Cancel/Calibrate	
		Forward Collision Warning Distance	Changes CMBS™ alert distance.	Long/Normal*1/Short	
	Driver Assist System Setup	ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC with Low Speed Follow range.	On/Off ^{*1}	
Vehicle		Assist System — Setup	Blind Spot Info	Changes the setting for the blind spot information.	Audible and Visual Alert ^{*1} /Visual Alert/Off
			Lane Keeping Assist Suspend Beep	Causes the system to beep when LKAS is suspended.	On/Off*1
		Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	Normal ^{*1} /Wide/Warning Only/Narrow	
		Driver Attention Monitor	Changes the setting for the driver attention monitor.	Tactile And Audible Alert ^{*1/} Tactile Alert/OFF	

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle	Meter Setup	Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	-5°F ~ ±0°F*1 ~ +5°F
		"Trip A" Reset Timing	Changes the setting of how to reset trip meter A and average fuel economy A.	When Refueled/IGN Off/ Manually Reset ^{*1}
		"Trip B" Reset Timing	Changes the setting of how to reset trip meter B and average fuel economy B.	When Refueled/IGN Off/ Manually Reset ^{*1}
		Adjust Alarm Volume	Changes the alarm volume, such as buzzers, warnings, turn signal sound, and so on.	High/Mid ^{*1} /Low
		Reverse Alert Tone	Causes the beeper to sound when you move to $[\mathbf{R}]$.	On ^{*1} /Off
		Fuel Efficiency Backlight	Turns the ambient meter feature on and off.	On ^{*1} /Off
		Turn By Turn Auto Display	Selects whether the turn-by-turn display comes on during the route guidance.	On*1/Off
		New Message Notifications	Used to select whether a pop-up alert comes on the screen when HFL receives a new text/e-mail message.	On*1/Off
		Speed/Distance Units	Selects the trip computer units.	mph · miles ^{*1} /km/h · km

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle	Driving Position Setup	Memory Position Link	Turns the driving position memory system on and off.	On*1/Off
	Keyless Access Setup	Remote Start System On/Off	Turns the remote engine start feature on and off.	On*1/Off
		Door Unlock Mode	Changes which doors unlock when you grab the driver's door handle.	Driver Door Only ^{*1} /All Doors
		Keyless Access Light Flash	Causes some exterior lights to flash when you unlock/lock the doors.	On*1/Off
		Keyless Access Beep	Causes the beeper to sound when you unlock/lock the doors.	On*1/Off
	Lighting Setup	Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	60seconds/30seconds*1/ 15seconds
		Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60seconds/30seconds/ 15seconds*1/0seconds
		Auto Light Sensitivity	Changes the timing for the headlights to come on.	Max/High/Mid ^{*1} /Low/Min
		Auto Interior Illumination Sensitivity	Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in the AUTO position.	Min/Low/Mid ^{*1} /High/Max

Setup Group	Custo	omizable Features	Description	Selectable Settings
Vehicle	Lighting Setup	Auto Headlight ON With Wiper ON	Changes the settings for the wiper operation when the headlights automatically come on while the headlight switch is in the AUTO position.	On*1/Off
		Auto Door Lock	Used to change the setting for when the doors automatically lock.	With Vehicle Speed ^{*1} /Shift from P/Off
		Auto Door Unlock	Changes the setting for when the doors unlock automatically.	All Doors When Driver's Door Opens ^{*1} /All Doors When Shifted to Park/All Doors When Ignition Switched Off/Off
	Door/ Window	Key and Remote Unlock Mode	Sets up the driver's door or all the doors to unlock on the first push of the remote.	Driver Door*1/All Doors
	Setup	Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	On*1/Off
		Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	90seconds/60seconds/ 30seconds*1
		Walk Away Auto Lock	Changes the settings for the auto lock function when you walk away from the vehicle.	On/Off ^{*1}

Setup Group	Customizable Features		Description	Selectable Settings
	Power Tailgate Setup*	Hands Free Access Function [*]	Changes the setting to open power tailgate by a swift forward in and out kicking motion under the rear bumper.	On*1/Off
		Keyless Open Mode	Changes the keyless setting for when the power tailgate opens.	Anytime ^{*1} /When Unlocked
Vehicle		Power Open By Outer Handle	Changes the setting to open power tailgate by tailgate outer handle.	Off (Manual only)/ On (Power/ Manual)*1
	Maintenan	ce Info.	Used to reset the maintenance minder information display when the maintenance service has been performed.	_
	Default		Cancels/Resets all customized items in the Vehicle settings group as default.	Yes/No
Smartnhono	Apple CarPlay		Sets up the Apple CarPlay™ connection.	—
Smartphone	Android Auto		Sets up the Android Auto™ connection.	_

Defaulting All the Settings

Reset all the menu and customized settings as the factory defaults.



- 1. Select 💼.
- 2. Select Settings.
- 3. Select System.
- 4. Select the Others tab.
- 5. Select Factory Data Reset.
- A confirmation message appears on the screen.
- 6. Select Next, then select Yes to reset the settings.
- 7. Select Yes again to reset the settings.
 - ► A confirmation message appears on the screen. Select **OK**.
 - ► After selecting **OK**, the system will reboot.

Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

If you perform **Factory Data Reset**, it will reset the preinstalled apps to their factory default.

If you perform **Factory Data Reset**, you cannot use the HondaLink[®] because it becomes off line. **D HondaLink[®]** P. 326