





■ Customized Features


Use the multi-information display to customize certain features.

■ How to customize


Select the **Vehicle Settings** screen by pressing the  button while the ignition switch is in ON ^{*1}, the vehicle is at a complete stop, and the shift lever is in . Press the **SEL/RESET** button to enter the customizing mode.



» Customized Features

To customize other features, press the  button.

- ▶ **List of customizable options** P. 130
- ▶ **Example of customization settings** P. 134

When you customize settings, shift to .



*1: Models with the keyless access system have an **ENGINE START/STOP** button instead of an ignition switch.


Customized Features

Models with color audio system

Use the audio/information screen to customize certain features.


■ How to customize

While the vehicle is at a complete stop with the ignition switch in ON , press the **MENU/CLOCK** button, then select **Settings**. To customize the phone settings, press the  button, then select **Phone Setup**.



» Customized Features

When you customize settings:



- Make sure that the vehicle is at a complete stop.
- Shift to .

» How to customize

These indications are used to show how to operate the selector knob.

Rotate  to select.

Press  to enter.


To customize other features, select **Settings**, rotate , then press .


➔ **List of customizable options** P. 353

Continued

■ Customization flow


Press the **MENU/CLOCK** button.





Features


Press the  button and rotate  to select **Phone Setup**, then press .



■ List of customizable options

Setup Group	Customizable Features	Description	Selectable Settings	
Settings	Adjust Clock	Adjusts the clock. 🔗 Clock P. 138	—	
	Bluetooth	Add New Device	Pairs a new phone to HFL, edits and deletes a paired phone, and create a code for a paired phone. 🔗 Phone Setup P. 380	—
		Connect an Audio Device	Connects, disconnects or pairs a <i>Bluetooth</i> ® Audio device to HFL.	—
	Display Adjustment	Brightness	Changes the brightness of the audio/information screen.	—
		Contrast	Changes the contrast of the audio/information screen.	—
		Black Level	Changes the black level of the audio/information screen.	—
	Rear Camera	Camera Guideline	Selects whether the guidelines come on the audio/information screen.	On *1/ Off

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Settings	Display Change	Changes the display type.	Audio^{*1}/Wallpaper
	Select	Changes the wallpaper type.	Clock^{*1}/Image1/Image2/ Image3
	Wallpaper	Imports an image file for a new wallpaper.  Wallpaper Setup P. 241	—
	Import		
	Delete	Deletes an image file for a wallpaper.	Image1^{*1}/Image2/Image3
	Color Theme	Changes the background color of the audio/ information screen.	Blue^{*1}/Red/Amber/Gray
	Language	Changes the display language.	English^{*1}/Français/Español
	Clock Format	Selects the digital clock display from 12H to 24H.	12h^{*1}/24h

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings	
Phone Setup	Add New Device	Pairs a new phone to HFL. ➤ Phone Setup P. 380	—	
	Bluetooth Setup	Connect a Phone	Pairs a new phone or connects a paired phone to HFL. ➤ Phone Setup P. 380	—
		Connect an Audio Device	Connects a <i>Bluetooth</i> ® Audio device to HFL.	—
		Disconnect All Devices	Disconnects a paired phone from HFL.	—
		Delete Device	Deletes a paired phone.	—
		Pass-Key	Inputs and changes a code for a paired phone.	—
	Speed Dial	Edits, adds or deletes a speed dial entry. ➤ Speed Dial P. 387	—	
	Ringtone	Selects the ring tone.	Fixed*1/Mobile Phone	
	Caller ID Info	Prioritizes the caller's name or phone number as the caller ID.	Name Priority*1/Number Priority	
	System Clear	Cancels/Resets all customized items in the Phone Setup group as default.	—	


*1:Default Setting

Models with display audio system

Use the audio/information screen to customize certain features.

■ How to customize

With the ignition switch in ON ^{*1}, select **Settings**, then select a setting item.



*1: Models with the keyless access system have an **ENGINE START/STOP** button instead of an ignition switch.

Customized Features


When you customize settings:

- Make sure that the vehicle is at a complete stop.
- Shift to **P**.

To customize other features, select **Settings**.


➤ **List of customizable options** P. 362

■ Customization flow




Features

* Not available on all models



*1: May change depending on your currently selected source.


* Not available on all models




Features

* Not available on all models

Continued




* Not available on all models





Features

■ List of customizable options

Setup Group	Customizable Features	Description	Selectable Settings		
Clock/Info	Clock	Clock	Changes the clock display type.	Analog/Digital^{*1}/Small Digital/Off	
		Wallpaper	<ul style="list-style-type: none"> Changes the wallpaper type. Imports an image file for a new wallpaper. Deletes an image file for a wallpaper. 	Galaxy^{*1}/Metallic/Time Zone/Blank	
	Clock	Clock/Wallpaper Type			
		Clock Adjustment	Adjusts clock.  Adjusting the Clock P. 138	—	
		Auto Time Zone[*]	Automatically adjusts the clock when driving through different time zones.	On^{*1}/Off	
		Manual Time Zone	Changes the time zone manually.	—	
		Auto Daylight Saving Time	Select On to have the GPS automatically adjust the clock to daylight savings time. Select Off to cancel this function.	On^{*1}/Off	
		Clock Format	Selects the digital clock display from 12H to 24H.	12H^{*1}/24H	
		Clock Display	Selects whether the clock display comes on.	On^{*1}/Off	
		Overlay Clock Location	Changes the clock display layout.	Upper Right^{*1}/Upper Left/Lower Right/Lower Left/Off	
HondaLink	Clock Reset	Resets the clock settings to the factory default.	Yes/No		
	Diagnostic & Location Data	Turns HondaLink® on and off.	On/Off^{*1}		

*1:Default Setting

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Clock/Info	Other Info Screen Preference	Selects the top menu when the  button is pressed. <ul style="list-style-type: none"> • Info Top- A brief menu pops up. • Info Menu- A full menu pops up. • Off- A menu does not pop up. 	Info Top/Info Menu/Off^{*1}
	Default	Cancels/Resets all customized items in the Clock/Info settings group as default.	Yes/No
Phone	Bluetooth Device List	Pairs a new phone to HFL, connects or disconnects a paired phone.  Phone Setup P. 404	—
	Ring Tone	Selects the ring tone.	Fixed/Mobile Phone^{*1}
	Automatic Phone Sync	Sets a phonebook and call history data to be automatically imported when a phone is paired to HFL.	On^{*1}/Off
	Auto Phone Call Transfer	Sets calls to automatically transfer from your phone to HFL when you enter the vehicle.	On^{*1}/Off
	HondaLink Assist	Turns HondaLink Assist on and off.	On/Off^{*1}
	Enable Text Messages	Turns the text message function on and off.	On^{*1}/Off
	New Message Notification	Selects whether a pop-up alert comes on the screen when HFL receives a new text message.	On/Off
Default	Cancels/Resets all customized items in the Phone settings group as default.	Yes/No	

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings	
Audio	Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone. ▶ Phone Setup P. 404	—	
	Common	Sound	Adjusts the settings of the audio speaker's sound. ▶ Adjusting the Sound P. 275	-6 ~ 0*1 ~ +6 (BASS, MIDDLE, and TREBLE), RR9~0*1~FR9 (FADER), L9~0*1~R9 (BALANCE), Off/Low/Mid*1/High (SVC)
		iPod, USB mode [Your selected media] Cover Art	Turns the cover art display on and off.	On*1/Off
	Audio Source Pop-Up	Selects whether the list of selectable audio source comes on when Audio is selected on the home screen.	On/Off*1	
	FM/AM mode FM/AM	HD Radio Mode (FM)*	Selects whether the FM radio automatically switches to the digital radio waves or receives the analog waves only.	Auto*1/Analog Only
		HD Radio Mode (AM)*	Selects whether the AM radio automatically switches to the digital radio waves or receives the analog waves only.	Auto*1/Analog Only
	RDS Info	Turns on and off the RDS information.	On/Off*1	

*1:Default Setting

* Not available on all models


Setup Group	Customizable Features	Description	Selectable Settings	
Audio	TuneStart	Turns on and off, starts the song from the beginning as you change preset stations.	On*¹/Off	
	SportsFlash Setup	Interrupt	Turns on and off the sports alert function.	Off/On(one time)/ On(continue)*¹
		Favorite Team	Selects your favorite sports teams. ▶ Live Sports Alert P. 291	—
		Interrupt Beep	Causes the system to beep when the sports alert is notified.	On*¹/Off
	Traffic & Weather Setup	Selects the region you want to receive the information.	—	
	Multiple Channel Mix Preset	Turns multiple channel mix preset on and off.	On/Off*¹	
Default	Cancels/Resets all customized items in the Audio settings group as default.		Yes/No	
Camera	Rear Camera	Fixed Guideline	Selects whether the fixed guidelines come on the rear camera monitor. ▶ Multi-View Rear Camera P. 515	On*¹/Off
		Dynamic Guideline	Selects whether the guidelines adjust to the movement of the steering wheel. ▶ Multi-View Rear Camera P. 515	On*¹/Off
	Default	Cancels/Resets all customized items in the Rear Camera setting group as default.		Yes/No

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings		
Camera	Show with Turn Signal	Selects whether the LaneWatch display comes on when you move the turn signal lever to indicate a right turn.	On^{*1}/Off		
	LaneWatch[*] Display Time after Turn Signal Off	Changes the length of time the LaneWatch display stays on after the turn signal lever returns to the center.	0 second^{*1}/2 seconds		
	Reference Line	Selects whether the reference lines come on the LaneWatch monitor.	On^{*1}/Off		
	Default	Cancels/Resets all customized items in the LaneWatch group as default.	Yes/No		
System	HOME Home Screen Edit Order	Changes the HOME screen icon layout.	—		
	Display	Brightness	Changes the brightness of the audio/information screen.	—	
		Display Settings	Contrast	Changes the contrast of the audio/information screen.	—
			Black Level	Changes the black level of the audio/information screen.	—
		Background Color	Changes the background color of the audio/information screen.	Blue^{*1}/Amber/Red/Violet/BlueGreen	

*1:Default Setting

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
System	Sound/ Beep	Guidance Volume Changes the sound volume. Adjusts the guidance volume of the navigation system.	1~6*~11
		Text Message Volume Changes the text message reading volume.	1~6*~11
		Voice Recog. Volume Changes the volume of the voice prompt.	1~6*~11
		Verbal Reminder Turns the verbal reminders on and off.	On*¹/Off
		Beep Volume Changes the beep volume.	Off/1/2*¹/3
	Voice Recog.	Voice Prompt Turns the voice prompt on and off.	On*¹/Off
		Voice Recog. Volume Changes the volume of the voice prompt.	1~6*~11
		Song by Voice*¹ Turns the Song By Voice™ on and off.	On*¹/Off
		Song by Voice Phonetic Modification*¹ Modifies a voice command for music stored in the system or an iPod/iPhone. ▶ Phonetic Modification P. 299	—
		Phone book Phonetic Modification Modifies a voice command for the phonebook. ▶ Phonebook Phonetic Modification P. 413	—
Automatic Phone Sync Sets phonebook and call history data to be automatically imported when a phone is paired to HFL.	On*¹/Off		
One Press Voice Operation Changes the setting of the  (Talk) button operation when using the voice operation.	On*¹/Off		

*1:Default Setting

* Not available on all models

Continued

Setup Group	Customizable Features	Description	Selectable Settings	
System	Clock	Clock/Wallpaper Type	Clock Wallpaper	
		Clock Adjustment		
		Auto Time Zone*		
		Manual Time Zone		
		Auto Daylight Saving Time	See Clock/Info on P. 362	
		Clock Format		
		Clock Display		
		Overlay Clock Location		
		Clock Reset		
		Other	Language	Change the display language.
	Remember Last Screen		Selects whether the device remembers the last screen.	On/Off* ¹
Memory Refresh	Turns on the audio system automatically and restores the fragmentation of a memory when the ignition switch is LOCK [0]* ² .		On* ¹ /Off	
Refresh Time Adjustment	Sets the time for Memory Refresh .		—	
Touch Panel Sensitivity	Sets the sensitivity of the touch panel screen.		High/Low* ¹	
	Detail Information	Displays the details of the head unit and operating system information.	—	

*1:Default Setting

*2:Models with the keyless access system have an **ENGINE START/STOP** button instead of an ignition switch.


* Not available on all models


Setup Group	Customizable Features	Description	Selectable Settings
System	Other	Factory Data Reset Resets all the settings to their factory default. ▶ Defaulting All the Settings P. 370	Yes/No
	Default	Cancels/Resets all customized items in the System group as default.	Yes/No
Bluetooth/ Wi-Fi	Bluetooth	Bluetooth On/Off Status Changes the <i>Bluetooth</i> ® status.	On* ¹ /Off
	Bluetooth	Bluetooth Device List Pairs a new phone to HFL, edits or deletes a paired phone. ▶ Phone Setup P. 404	—
	Bluetooth	Edit Pairing Code Edits a pairing code. ▶ To change the pairing code setting P. 405	Random/Fixed* ¹
	Wi-Fi	Wi-Fi On/Off Status Changes the Wi-Fi mode.	On/Off* ¹
	Wi-Fi	Wi-Fi Device List Connects, disconnects, or deletes the Wi-Fi device.	—
	Wi-Fi	Wi-Fi Information Shows the Wi-Fi information of the head unit.	—
	Default	Cancels/Resets all customized items in the Bluetooth/Wi-Fi group as default.	Yes/No
Smartphone	Apple CarPlay	Sets up the Apple CarPlay connection.	—
	Android Auto	Sets up the Android Auto connection.	—

*1:Default Setting

Defaulting All the Settings

Reset all the menu and customized settings as the factory defaults.



1. Select .
2. Select **Settings**.
3. Select **System**.
4. Select the **Others** tab.
5. Select **Factory Data Reset**.
 - A confirmation message appears on the screen.
6. Select **Yes** to reset the settings.
 - A confirmation message appears on the screen. Select **OK**.
 - After selecting **OK**, the system will reboot.
7. Select **Yes** again to reset the settings.
 - A confirmation message appears on the screen. Select **OK**.
 - After selecting **OK**, the system will reboot.

Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

If you perform **Factory Data Reset**, it will reset the preinstalled apps to their factory default.

If you perform **Factory Data Reset**, you cannot use the HondaLink® because it becomes off line.

 **HondaLink®** P. 308