

ECO ASSIST™

Provides various ways to monitor your fuel efficiency and driving style.

Activating the ECON Mode

1. Press ECON.



3. Check the MID.



2. The ECON mode indicator comes on.




4. Press either INFO (▲/▼) button and toggle to the Ecological Drive Display.



Note: When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system are adjusted to maximize fuel efficiency.

Driver Feedback



Real-time Fuel Efficiency Coach

| Driving Style | Eco Drive Bar (on the MID) | Ambient Meter Background Color Changes | Fuel Efficiency |
|---|----------------------------|--|--------------------------------------|
| Smooth, steady acceleration maximizes fuel efficiency | | | <p>High</p> <p>Low</p> |
| Smooth, steady deceleration maximizes fuel efficiency | | | |
| Moderate acceleration | | | |
| Moderate deceleration | | | |
| Rapid acceleration lowers fuel efficiency | | | |
| Rapid deceleration lowers fuel efficiency | | | |

- Goals:**
- Keep the Eco Drive Meter near the **GREEN**.
 - Develop a driving style that maximizes fuel efficiency.

NORMAL/ECON mode shown


ECO Assist Scoring

Monitors the fuel efficiency of your driving style in real time and converts results into leaves, which are displayed in a series of five "plant" icons on the MID.

Once you start your vehicle, make sure the MID shows the Ecological Drive Display on the display to view your Eco Assist score in real time.



As you drive, you earn leaves if you drive in a fuel-efficient manner, or lose them if you drive inefficiently.



When you turn the ignition off, your drive cycle and lifetime score are displayed on the MID.



Eco Score

Each time you reach a new stage, a Stage Up Recognition icon briefly appears on the MID. When you reach the highest ranking, a trophy icon briefly appears.

