



FUEL FILL DOOR

Easy-to-open fuel door keeps your fuel cap covered.

Opening and Closing the Fuel Fill Door

To open, push and release the fuel door in the area shown until you hear a click and it pops open.



To close, push the fuel door flush with the body.

