



## Touchscreen Operation

Use simple gestures—including touching, swiping, and scrolling—to operate certain audio functions.

Some items may be grayed out during driving to reduce the potential for distraction. You can select them when the vehicle is stopped or use voice commands\*.

Wearing gloves may limit or prevent touchscreen response.

### Models with touchscreen




*\*\*if equipped*

*\*\*HondaLink can be accessed only if the app is installed on your smartphone, and the phone is connected to the system.*

### Changing Icon Order

You can change the order of the icons on the Home screen.

- From the Home screen, select Settings.
- Select System.
- Select the Home tab.
- Select Home Screen Edit Order.
- Select and hold the icon you want to move and slide it to a different position.



## HondaLink™

You can connect a compatible smartphone to the audio system to enable integration between the smartphone's approved apps and the vehicle. This allows you to control the phone's apps through the touchscreen.



To check smartphone compatibility and connection instructions, visit [handsfreelink.honda.com](http://handsfreelink.honda.com).

To get more information on HondaLink features and apps, visit [www.hondalink.com](http://www.hondalink.com).

## FM/AM Radio

Play FM or AM radio stations.



### Models with touchscreen



## SiriusXM® Radio

Available on a subscription only. For more information or to subscribe, contact your dealer, or visit [www.siriusxm.com](http://www.siriusxm.com) (U.S.) or [www.sirius.ca](http://www.sirius.ca) (Canada).

### Models with touchscreen





*Available in the U.S. and Canada, except Hawaii, Alaska, and Puerto Rico. XM® is a registered trademark of Sirius XM Radio, Inc.*

## Compact Disc (CD)

The audio system supports audio CDs, CD-Rs, and CD-RWs in MP3, WMA, or AAC formats.

### Models with touchscreen



### NOTICE



Do not use CDs with adhesive labels or insert a damaged CD. Inserting these types of CDs may cause them to get stuck or damage the audio unit.

## iPod®

Play and operate an iPod through the vehicle's audio system.

### Models with touchscreen


Connect your device to the USB port.



### Searching for Music

Use the touchscreen to search for tracks stored on the iPod.

- From the audio screen, press MENU.
- Select Music Search.
- Select a search option.
- Select the track you want to play.





## USB Flash Drive

Play and operate a USB flash drive through the vehicle's audio system.

### Models with touchscreen


Connect your device to the USB port.



### Searching for Music

Use the touchscreen to search for tracks stored on the USB flash drive.

- From the audio screen, press MENU.
- Select Music Search.
- Select a folder.
- Select the track you want to play.



## Bluetooth® Audio

Play streaming or stored audio from your compatible phone through the vehicle's audio system. Visit [handsfreelink.com](http://handsfreelink.com) (U.S.) or [handsfreelink.ca](http://handsfreelink.ca) (Canada) to check phone compatibility. Standard data rates apply.

### Models with touchscreen

Connect your phone to *Bluetooth® HandsFreeLink®*.



### Notes:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional settings on your phone for playback.
- The resume/pause function and remote audio controls are not supported on all phones.

*State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle. Only launch streaming audio on your phone when it is safe to do so.*