

REVERSE TILT DOOR MIRRORS

When you shift into Reverse (R), you can tilt either door mirror down slightly to improve your view as you parallel park. Shifting out of Reverse returns the tilted mirror to its original position.

How It Works



- To tilt the driver's door mirror, move the mirror selector switch to the left (L) position.
- To tilt the passenger's door mirror, move the mirror selector switch to the right (R) position.
- To turn the feature off, move the switch to the middle position.

