


Models with touchscreen

SiriusXM® Radio*

Available on a subscription basis only. For more information or to subscribe, contact your dealer, or visit www.siriusxm.com (U.S.) or www.sirius.ca (Canada).



Source: Select the XM icon.

Scan: Scan each station with a strong signal.

Category: Change the category.


Presets: Select and hold a preset number to store the current station. Select a preset number to select a previously stored station.

Channel: Change the channel. Press and hold to skip 10 channels at a time.

Open/close: Display or hide the channel list or preset list.

TAG*: Tag a song to store to an iPod/iPhone for later purchase or download.

Skip: Change the selection. Press and hold to skip rapidly.



To learn about additional features—such as multi-channel preset, replay, or SportsFlash—see your Owner's Manual on the Owner Information CD or visit owners.honda.com (U.S.) or myhonda.ca (Canada).