



Multi-Information Display (MID)*

Consists of several displays that provide you with useful information.




■ Main Displays

Press either Info (▲/▼) button to cycle through the displays shown below.



■ Lower Displays

Press the SEL/RESET button to cycle through the displays shown below.



■ Vehicle Settings


Use the MID to customize certain vehicle features when the vehicle is in Park (P) or the parking brake is applied. You can also use the SETTINGS button*.

An example of how to change the Trip A reset timing setting is below. Use the Info (▲/▼) and SEL/RESET buttons to make and enter selections.

1. Scroll to the Vehicle Settings menu and select it.



2. Scroll to Meter Setup and select it.



3. Scroll to "Trip A" Reset Timing and select it.



4. Scroll through the options, and select the one you want.

5. Scroll to Exit, and select it to exit the menus.

