



Information Display*

Consists of several displays that provide you with useful information.




Press the select/reset knob to change displays.



**if equipped*


Multi-Information Display (MID)*

Consists of several displays that provide you with useful information.




Main Displays

Press the Info buttons to change main displays.



Lower Displays


Press the SEL/RESET button to change lower displays.



*if equipped

■ Changing Settings Using the MID

Use the Info and SEL/RESET buttons to operate the Vehicle Settings menu in the MID. The vehicle must be in Park (P) to enter the menu.



Press the Info buttons to scroll to the Vehicle Settings screen. Press the SEL/RESET button to enter the menu.

Info buttons: Scroll through menu options.

SEL/RESET button: Select a menu option.