BLUETOOTH® HANDSFREELINK® (HFL)

Learn how to operate the vehicle's hands-free calling system.


Basic HFL Operation

Make and receive phone calls using the vehicle's audio system, without handling your phone. Visit *handsfreelink.com* (U.S.) or *handsfreelink.ca* (Canada) to check phone compatibility.


To reduce the potential for driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Stop or pull over to perform the function. Voice commands are also available.

HFL Controls

Use the controls to enter information and make selections.







Talk Button Tips

For a list of available phone commands, see page 117.

- When using the Talk button, wait until you hear a beep before speaking.
- To bypass the system prompts, simply press the Talk button again to say your command.*
- When the Talk button is pressed, all available voice commands are highlighted in yellow.*
- Speak in a clear, natural voice.
- Reduce all background noise.
- Close the windows.

Pairing a Phone

To use hands-free phone and streaming audio functions, you must first pair your phone to the system. This can only be done when the vehicle is stopped. Use the touchscreen to make and enter selections.

- 1. From the HOME screen, select Settings.
- 2. Select Phone.
- 3. Select Bluetooth Device List.
- 4. Select Add Bluetooth Device.
- 5. Make sure your phone is in discovery mode. Select Continue.
- The system searches for your phone. Select your phone when it appears on the list. *If your phone does not appear:* Select Phone Not Found and search for HandsFreeLink from your phone. Connect to HFL.
- The system gives you a pairing code. Compare it to the code that appears on your phone. Connect to HFL from your phone.
- The system asks if you want to enable options: HondaLink Assist: Select On to enable emergency collision notification (see page 53). Automatic Phone Sync: Select On to automatically import contacts and call history from your phone.
- 9. Press the BACK button to exit the menu.



State, provincial, or local laws may prohibit the operation of handheld electronic devices while operating a vehicle.

Making a Call

You can make a call using several methods.

Dialing a Number

Enter a 10-digit phone number to call.

Using voice commands

Press the Talk button and say *"Call"* and the phone number. For example, *"Call 3-1-0-5-5-5-1-2-3-4."* The system begins the call.

Using the touchscreen

Manual operation is limited while the vehicle is moving. Voice commands are always available.

- 1. From the HOME screen, select Phone.
- 2. Press the MENU button.
- 3. Select Dial.
- 4. Enter the phone number. Select the green phone icon to call.

Using the Phonebook

When your phone is paired, its entire phonebook can be automatically imported to the system. Automatic Phone Sync must be turned on.

Using voice commands

Press the Talk button and say *"Call"* and the phonebook name and type. For example, *"Call John Smith mobile."* The system begins the call.

Using the touchscreen

Manual operation is limited while the vehicle is moving. Voice commands are always available.

- 1. From the HOME screen, select Phone.
- 2. Press the MENU button.
- 3. Select Phonebook.
- Scroll through the list to find the name and number you want to call, and select it to call.

Phonebook			0	ota 10:00			
< AND \					MNO		
AAA							
AAB							
AAC							
BBB				ê 1	1		
ccc				÷			
		Search					







Storing Speed Dial Entries

Store up to 20 numbers for quick dialing.

- 1. From the HOME screen, select Phone.
- 2. Press the MENU button.
- 3. Select Speed Dial, then select New Entry.
- 4. Select an entry method.
- 5. If desired, you can create a voice tag for the number. Follow the prompts.

Using Speed Dial

Make calls quickly using stored speed dial entries.

Using voice commands

Press the Talk button and say "Call" and the stored voice tag name. For example, "Call John Smith."

Using the touchscreen

- 1. From the HOME screen, select Phone.
- 2. Scroll through the list to find the entry you want to call, and select it to call.





