


Seat Heaters*

Quickly warm the seats when the vehicle is on.

Press the seat heater button in the front console. An indicator appears for the selected setting.

- Once: HI setting (three indicators)
- Twice: MID setting (two indicators)
- Three times: LO setting (one indicator)
- Four times: OFF setting (no indicators)



WARNING

Heat-induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lower-limb nerve damage, or paralysis) or with sensitive skin should not use the seat heaters.

**if equipped*