Panoramic Glass Roof*

The ceiling cover in the second row can be opened and closed to reveal the glass roof when the vehicle is on by using the switch on the ceiling.

Automatic Operation

To open: Push the switch back firmly, then release.

To close: Push the switch forward firmly, then release.

The cover opens completely. To stop the cover in either direction, push the switch briefly.

Manual Operation

Open Close

To open: Push and hold the switch back lightly until the desired position is reached.

To close: Push and hold the switch forward lightly until the desired position is reached.

Closing the roof on someone's hands or fingers can cause serious injury.

Make sure your passengers are away from the roof before closing it.