

■ Starting and Stopping the Engine / Changing the Power Mode*

Use the ENGINE START/STOP button to cycle through power modes or start the engine.

Accessory or On mode: Press ENGINE START/STOP once without pressing the brake pedal for Accessory mode. Press it again for On mode.

Starting the engine: Press and hold the brake pedal or clutch, then press ENGINE START/STOP. Keep your foot firmly on the brake pedal when starting the engine.

Turning the vehicle off

Models with continuously variable transmission

Shift to Park (P) or apply the parking brake, then press ENGINE START/STOP. If you press the button and the shift lever is not in Park (P), the vehicle goes into Accessory mode.

Models with manual transmission

If the shift lever is in neutral, press the ENGINE START/STOP button. If the vehicle is in gear, depress the clutch pedal, then press the ENGINE START/STOP button.

