


Climate Control System*

The automatic climate control system can maintain your preferred interior temperature by selecting the proper mix of heated or cooled air and fan speed. Touch the icons on the dashboard to control the system.

U.S. models




VEHICLE CONTROLS

■ Passenger Side Vents

Three separate front passenger side air vents allow for different air flow rates through the vehicle.

Adjust each vent to optimize airflow throughout the vehicle.



Open or close individual vents to adjust passenger comfort levels.

