


## HondaLink Assist

If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle automatically attempts to connect to an operator. Your phone must be paired to the system and have good cellular connection. Visit [www.hondalink.com](http://www.hondalink.com) (U.S.) or [honda.ca/hondalinkassist](http://honda.ca/hondalinkassist) (Canada) for more information.

1. Make sure your phone is on and paired to *Bluetooth HandsFreeLink* (see page 85).
2. Select **Call Now**, or the system automatically connects after 10 seconds. The vehicle information and its position are sent to the operator.
3. Select **Talk Now** to immediately talk to the operator.
4. When the call is complete, select **Hang Up** or press the Hang-Up/Back button on the steering wheel.



*\*if equipped*