



■ Paddle Shifters*

Use the paddle shifters to change gears from 1st through 7th without removing your hands from the steering wheel.

(-) paddle shifter:
Pull to shift down
to a lower gear.



(+) paddle shifter:
Pull to shift up to
a higher gear.



M indicator/gear
position indicator

When the shift lever is in D: The vehicle goes into manual shift mode temporarily and the gear number appears. When you start traveling at a constant speed, or pull the (+) paddle for a few seconds, manual shift mode automatically switches off and the gear number goes off.

When the shift lever is in S: The vehicle goes into manual shift mode and the M indicator and gear number appear. When the vehicle comes to a stop, it automatically shifts down into 1st gear. You can pull away only in 1st gear. If the vehicle speed increases and the engine speed approaches the tachometer's red zone, the transmission automatically shifts up. As the vehicle speed slows down, the transmission automatically shifts down accordingly.

To cancel manual shift mode, move the shift lever from S to D. The M indicator and gear number go off.