

## Power Moonroof Operation\*


The moonroof can be opened and closed when the vehicle is on by using the switch on the ceiling.

### ■ Automatic Operation

**To open:** Push the switch back firmly, then release.

**To close:** Push the switch forward firmly, then release.

The moonroof opens or closes completely. To stop the moonroof at any time, push the switch briefly.



### ■ Manual Operation

**To open:** Push and hold the switch back until the desired position is reached.

**To close:** Push and hold the switch forward until the desired position is reached.

### ■ Moonroof Tilt

**To tilt:** Push the center of the switch.

**To close:** Push the switch forward firmly, then release.

### NOTICE

Opening the moonroof in below freezing temperatures or when it is covered with snow or ice can damage the moonroof panel or motor.

### ⚠ WARNING

Closing the moonroof on someone's hands or fingers can cause serious injury. Make sure your passengers are away from the moonroof before closing it.

*\*if equipped*