

### ■ Steering Wheel Controls


You can operate certain functions of the audio system using the steering wheel controls.

**SOURCE button:** Cycle through available audio modes.

**◀/▶ buttons:** Change presets, tracks, albums, or folders.

**+ / - buttons:** Adjust audio volume.

**Menu button\*:** From the audio screen, press to choose options for the current audio mode. Use the +/- buttons and the SOURCE button to scroll and enter selections.



### FM/AM/SiriusXM Radio\*

Press **◀** or **▶** for the next or previous station.

Press and hold **◀** or **▶** for the next or previous strong station.

### CD\*/iPod/USB/Bluetooth® Audio

Press **◀** or **▶** for the next or previous track.

Press and hold **◀** or **▶** for the next or previous folder (CD\*/USB).

### Pandora (U.S. only)

Press **▶** for the next song.

Press and hold **◀** or **▶** for the next or previous station.

*\*if equipped*